



Can LH<sub>2</sub> Save Antarctica?..... 11  
Emissions-Free Flight..... 12  
LCLS-II's 'First Light'..... 14

Cryo-Engineering for SRF ..... 78  
Revolutionizing Cryogenics Connectivity..... 84  
Innovating Cryogenic Horizons ..... 86

# Cold Facts

## 2024 Buyer's Guide | Corporate Directory

The Magazine of the Cryogenic Society of America, Inc.

# INTERNATIONAL

### Products and Services

for Cryogenic and Superconductivity Applications Worldwide



# Specializing in Hydrogen & Helium Purification - Liquefaction - Refrigeration



Helium Liquefier Vacuum Cold Box - 1800 L/Hr



Hydrogen Liquefier Vacuum Cold Box - 10T/Day



Cryogenic Helium Purifier Vacuum Cold Box



Helium Liquefier Vacuum Cold Box - 835 L/Hr



Hydrogen Liquefier Vacuum Cold Box - 10T/Day



Custom-Engineered Cryogenic  
Industrial Gas Processing Systems

610.530.7288 [www.ChartIndustries.com/CryoTech](http://www.ChartIndustries.com/CryoTech)



WHEN PERFORMANCE AND RELIABILITY MATTER

- Cold boxes
- High vacuum chambers
- Pressure vessels
- Cryostats
- Helium compressor skids
- Thermal shrouds
- Thermal conditioning units
- Vacuum insulated piping
- Valves
- Couplings



- Cryopumps
- Cryocoolers

Proudly Manufactured in the USA

[info@phpk.com](mailto:info@phpk.com)

(614) 486 4750

[www.phpk.com](http://www.phpk.com)



# Strength in Numbers

**A legacy of reliability.  
Proven performance.**

For over half a century, researchers have turned to the SHI Cryogenics Group for the latest advancements in cryogenic technology. We think the numbers speak for themselves:

- Consistent reliability in **thousands of systems** worldwide
- Proven performance in **hundreds of applications**
- Over **five-hundred employees** around the world
- A full range of products, with over **forty models**
- A global installed base, supported by **twelve international offices**
- **One important customer: you**



Visit us anytime, worldwide. [www.shicryogenics.com](http://www.shicryogenics.com)

#### Asia

Sumitomo Heavy Industries, Ltd.  
Phone: +81 3-6737-2550 • [cryo@shi.co.jp](mailto:cryo@shi.co.jp)  
Sumitomo (SHI) Cryogenics Shanghai, Ltd.  
Phone: 86 21-54866318 • [ZCryo\\_ChinaSales@shi.co.jp](mailto:ZCryo_ChinaSales@shi.co.jp)  
Sumitomo (SHI) Cryogenics Korea, Co., Ltd.  
Phone: +82 31 278 3050 • [Won\\_Bum\\_Lee@shi.co.jp](mailto:Won_Bum_Lee@shi.co.jp)  
Sumitomo (SHI) Cryogenics Taiwan Co., Ltd.  
Phone: +886 3 561 2101/2557

#### Europe

Sumitomo (SHI) Cryogenics of Europe, Ltd.  
Phone: +44(0) 1256 853333  
[uksales@shicryogenics.co.uk](mailto:uksales@shicryogenics.co.uk)  
Sumitomo (SHI) Cryogenics of Europe, GmbH  
Phone: +49 (0) 6151 860 610  
[contact@sumitomocryo.de](mailto:contact@sumitomocryo.de)

#### United States



Sumitomo (SHI) Cryogenics of America, Inc.  
Phone: +1 610-791-6700  
[sales@shicryogenics.com](mailto:sales@shicryogenics.com)

# Join Our Growing Family of CSA Corporate Sustaining Members

Get connected to the cryogenic community worldwide. Let your voice be heard and your contributions known.

Abess Instruments and Systems, Inc.	CryoCoax	Imtek Cryogenics	shirokuma GmbH
Ability Engineering Technology, Inc.	Cryocomp	Independence Cryogenic Engineering, LLC	Sierra Lobo
Acme Cryogenics, Inc.	CryoEdge	Kelvin International Corporation	Signal Microwave
Ad-Vance Magnetics	Cryofab, Inc.	KEYCOM Corporation	SLAC-National Accelerator Laboratory
Advanced Research Systems, Inc.	Cryogas Tech Sdn. Bhd.	kiutra GmbH	Space Dynamics Laboratory
Aerospace Fabrication & Materials	Cryogenic Institute of New England	Lake Shore Cryotronics, Inc.	Spectrum Control
Air Liquide advanced Technologies	Cryogenic Limited	Lihan Cryogenics	SPS Cryogenics BV
Alkegen	Cryoguard LLC	Linde Cryogenics, Division of Linde Engineering Americas	STAR Cryoelectronics
Alloy Valves and Control	Cryomagnetics, Inc.	Magnatrol Valve Corporation	Stirling Cryogenics BV
American Magnetics, Inc.	Cryomech, Inc.	Magnetic Shield Corporation	Stöhr Armaturen GmbH & Co. KG
Ampo Poyam Valves (AMPO)	Cryonova Process Systems, LLC	Marathon Products, Inc.	Sumitomo (SHI) Cryogenics of America, Inc.
Amuneal Manufacturing Corp.	Cryospain	Meyer Tool & Mfg., Inc.	Sunpower, Inc.
Argonne National Laboratory	CryoSRV, LLC	Micro Harmonics Corporation	SuperPower, Inc.
Atlas Technologies	CryoTechnics LLC	Midalloy	Technifab Products, Inc.
Barber-Nichols LLC	CryoVac GmbH	Molecular Products, Inc	Technology Applications, Inc.
Beyond Gravity GMBH	CryoWorks, Inc.	NASA Kennedy Cryogenics Test Laboratory	Tech4 Imaging LLC
Bhiwadi Cylinders PVT	Cryoworld BV	National High Magnetic Field Laboratory	Tempshield Cryo-Protection
Bluefors	CSIC Pride (Nanjing) Cryogenic Technology Co., Ltd.	Nikkiso Cryogenic Industries	The Aerospace Corporation
BRUGG Pipes	Danaher Cryogenics	Niowave, Inc.	The Phoenix Company of Chicago
Canadian Nuclear Laboratories	Demaco Holland BV	Oak Ridge National Laboratory	Thermal Management Technologies
CCH Equipment Company	DMP CryoSystems, Inc.	Omega Flex, Inc.	Thermal Space
Chart Inc.	EPSIM Corporation	Oxford Cryosystems	Thomas Jefferson National Accelerator Facility
Chase Research Cryogenics	Equigas, Inc.	Oxford Instruments NanoScience	TRIUMF
Clark Industries, Inc.	Essex Industries	Penflex	Turbines Inc.
Coax Co., LTD.	Eta Space	Photon Spot	Vacuum Barrier Corporation
<b>Commonwealth Fusion Systems*</b>	Fabrum Solutions	PHPK Technologies	Vacuum Energy Inc.
CoolCAD Electronics, LLC	Facility for Rare Isotope Beams—Michigan State University	Princeton CryoTech	Valcor Engineering Corporation
CO2 Meter	Fermi National Accelerator Laboratory	Quantum Design, Inc.	Web Industries
CPC-Cryolab, an MEC Company	Fin Tube Products, Inc.	RegO	WEKA AG
Creare LLC	FormFactor	RIX Industries	Wessington Cryogenics
Criotec Impianti SpA	Gardner Cryogenics	Rockwood Composites	West Coast Solutions
Cryo Industries of America	Gas Equipment Company	Rutherford & Titan Inc.	XMA Corporation
Cryo Service LTDA	GenH2	Scientific Instruments, Inc.	ZeroAvia
Cryo Technologies	IC Biomedical		

\* New member since last issue



## 2023 BUYER'S GUIDE

- 25 **Products and Services**
- 42 **Alphabetical Listing**
- 56 **Supplier Profiles**

## FEATURES

- 8 Commonwealth Fusion Cryo Team's Just-in-Time Engineering
- 11 Can LH<sub>2</sub> Preserve Our Last Clean Continent?
- 12 H2FLY Pioneers Emissions-Free Flight with Successful Liquid-Hydrogen-Powered Aircraft
- 14 LCLS-II's 'First Light' Revolutionizes X-ray Science
- 16 Elevating Pipe Support Systems with "Lift-Off" Innovation
- 20 Cryogenics Drives Advancements in Aerospace Welding

## COLUMNS

- 6 Executive Director's Letter
- 41 Look who's NEW in the Cold Facts Buyer's Guide
- 78 Zero Resistance Zone: Cryo-Engineering for SRF

## SPOTLIGHTS

- 82 White Paper Explores Gas Monitoring in Food Storage Safety
- 84 CryoCoax Revolutionizes Cryogenic Connectivity
- 86 HeLIUM Cryogenics Redefines Cryogenic Technology
- 88 Advances in Manufacturing Yield a Clean ID Hose

## 90 PRODUCT SHOWCASE

## 92 PEOPLE & COMPANIES

## 92 CALENDAR

## ON OUR COVER



The Commonwealth Fusion System's (CFS) team is working on a high temperature superconducting magnet for SPARC, the CFS commercial fusion demonstration facility. Credit: Commonwealth Fusion Systems

In all instances, "CSA CSM" indicates a Corporate Sustaining Member of CSA.



Sunpower was CSA's newsletter sponsor for November.



Gardner Cryogenics was CSA's newsletter sponsor for December.

Cold Facts Magazine

Editor  
ANNE DiPAOLA

Advertising Coordinator  
JOE SULLIVAN

Online Marketing Manager  
JO SNYDER

Graphic Designer  
ISRAEL REZA

## CSA Board of Technical Directors

Board Chairman  
JOHN WEISEND II  
European Spallation Source (ERIC)

President  
AL ZELLER  
NHMFL, FSU

Past President  
JOHN PFOTENHAUER  
UNIVERSITY OF WISCONSIN-MADISON

President-Elect  
RICH DAUSMAN  
Bluefors

Executive Director  
MEGAN GALEHER  
Cryogenic Society of America

Managing Director  
RICK CHURCH  
Cryogenic Society of America

## Technical Directors

ROBERT DUCKWORTH, OAK RIDGE NATIONAL LAB

LUKAS GRABER, Georgia Institute of Technology

JASON HARTWIG, NASA GLENN RESEARCH CENTER

JOHN JURNS, NIST CENTER FOR NEUTRON RESEARCH

CARL S. KIRKCONNEL, West Coast Solutions

PETER KNUDSEN, University of Maryland, Laboratory for Physical Sciences

JACOB LEACHMAN, WASHINGTON STATE UNIVERSITY

MIKE MEYER, NASA Langley Research Center

SASTRY PAMIDI, FAMU-FSU COLLEGE OF ENGINEERING

CHRIS REY, Energy to Power Solutions (E2P)

STEVEN VAN SCIVER, FLORIDA STATE UNIVERSITY

ADAM SWANGER, NASA KENNEDY SPACE CENTER

STEVEN VAN SCIVER, FLORIDA STATE UNIVERSITY

Cold Facts (ISSN 1085-5262) is published six times per year by the Cryogenic Society of America, Inc. Contents ©2023 Cryogenic Society of America, Inc.

Although CSA makes reasonable efforts to keep the information contained in this magazine accurate, the information is not guaranteed and no responsibility is assumed for errors or omissions. CSA does not warrant the accuracy, completeness, timeliness or merchantability or fitness for a particular purpose of the information contained herein, nor does CSA in any way endorse the individuals and companies described in the magazine or the products and services they may provide.

## From the Executive Director



It's that time of year again! We are proud to present to you our 2024 edition of the printed Buyer's Guide – a resource of products and services designed for cryogenic applications. We hope you find this year's edition to be a useful tool for you to use throughout 2024 and beyond. As a reminder, you can always access the online version of our Buyer's Guide, which is updated regularly at [www.csabg.org](http://www.csabg.org).

With 2023 coming to a close, I enjoy reflecting on the successes CSA has experienced in the last year. The year began with a great issue of *Cold Facts*, published in February, spotlighting the next generation in cryogenics and superconductivity through our Young Professionals feature. We had a record turnout of submissions and were able to spotlight nine young professionals in total.

In July, we jetted off to Honolulu, Hawaii, to attend CEC/ICMC'23 and to host numerous CSA short courses which took place the day prior to the conference. These courses provided a comprehensive understanding of different aspects of cryogenics and were an excellent opportunity for students and researchers to enhance their knowledge and skills in the field.

During CEC/ICMC'23, CSA was able to host an exhibit table where we got to meet and visit with many of you! It's always a pleasure to chat with our readers and members to see how we can continue to improve our offerings. Also during CEC/

ICMC'23, CSA presented two awards – the Vance Award and the Mullholland Award. The Vance Award was presented to Rich Dausman to recognize his long-term support of the Cryogenic Society of America. The Mullholland Award was presented to Shrikant Pattalwar for his leadership in both the cryogenics and systems integration for the Daresbury Vertical Test Facility.

After CEC/ICMC'23, we hopped over to Kailua-Kona, Hawaii, for the 30th Space Cryogenics Workshop (SCW). SCW was a major success with more than 100 people in attendance. The event took place at the stunning Outrigger Kona Resort, which is an oceanfront resort on the Kona Coast overlooking Keauhou Bay. The workshop offered two days of oral and poster sessions. Attendees raved about the quality of session content and ample networking opportunities with industry colleagues. We look forward to hosting the 31st Space Cryogenics Workshop in the spring of 2025. More details coming soon!

Looking forward to 2024, I have some exciting personal news to share with you. My family and I will be welcoming a baby boy in February of 2024. I will be taking some time off to spend with our newest addition to the family. In my absence, the CSA team will all still be here working hard to provide you with great content through *Cold Facts* and the many other resources provided by CSA.

As always, I hope you enjoy this special Buyer's Guide issue of *Cold Facts*! Happy New Year! 🍷

## ColdFacts Editorial Board

Randall Barron,  
ret. Louisiana Tech University  
Jack Bonn, VJ Systems, LLC  
Robert Fagaly, ret. Honeywell  
Peter Kittel, ret. NASA Ames  
Glen McIntosh,  
Cryogenic Analysis and Design LLC

John Pfothenauer, University of Wisconsin-Madison  
Ray Radebaugh, ret. NIST Boulder  
Ralph Scurlock, Kryos Associates,  
ret. University of Southampton  
Nils Tellier, EPSIM Corporation

# Cryogenic Engineering and Safety Annual 5-Day Course

August 5-9, 2024  
Colorado School of Mines  
Golden, Colorado

This 5-day course is designed to provide a solid foundation in cryogenic engineering for both degreed and non-degreed engineers, including operations personnel and technicians using cryogenics.

Register Online at:  
[www.cryocourses.com](http://www.cryocourses.com)

## CRYOCO LLC

David-John Roth  
SME III Cryogenics  
[djroth@cryocourses.com](mailto:djroth@cryocourses.com)  
305-972-8847



On-site courses also available

## Looking for Solenoid Valves to Handle Liquid Oxygen, Argon and Nitrogen?



Magnatrol manufactures high quality, two-way bronze and stainless steel solenoid valves designed to provide rugged, durable service over a wide range of cryogenic applications.

- Type L and M (Bronze) and Type J and K (Stainless Steel) valves to handle liquid oxygen to (-297°), argon (-303°), and nitrogen (-320°)
- Valve pipe sizes from 3/8" up to 3"
- Continuous duty coils for all AC/DC voltages
- Wide range of options including manual override, position indicator, NEMA 4X explosion proof and watertight models, and many more
- All valves fully tested, degreased, and cleaned to keep them free of moisture

For more information, call 973-427-4341, Fax: 973-427-7611, E-mail: [info@magnatrol.com](mailto:info@magnatrol.com) or visit [www.magnatrol.com](http://www.magnatrol.com).



Magnatrol Valve Corporation  
67 Fifth Avenue • Hawthorne, NJ 07507

# Cryogenic Valves & Vacuum Components

## Large Inventory for Immediate Shipment

- ▼ Vacuum Jacketed Valves
- ▼ Vacuum Seal-Off Valves and Valve Operators
- ▼ Vacuum Relief Valves
- ▼ Coldbox Valves
- ▼ Vapor Vents and Heaters
- ▼ Pipe and Tube Sized Bayonets



## Vacuum Jacketed Manifolds & Custom Fabrications



For Reliable, Long-Life Cryogenic Components Contact  
[sales@cryocomp.com](mailto:sales@cryocomp.com)  
[www.cryocomp.com](http://www.cryocomp.com)



a division of Cryofab, Inc.

+1 908.686.3643

**CRYOCOMP**



The Commonwealth Fusion Systems magnet factory will support manufacturing of all the magnets for the company's SPARC device, which aims to be the first system to achieve net energy from magnetically confined fusion and a proof of concept for subsequent commercialization. Credit: Commonwealth Fusion Systems

# Commonwealth Fusion Cryo Team's Just-in-Time Engineering

by Andrew Dalesandro, Cryoplant Lead, Commonwealth Fusion Systems

High temperature superconducting (HTS) tapes, which have emerged over the last decade, are enablers for new technologies. Specifically, high temperature superconducting magnets to enable commercial fusion energy are arguably the most tantalizing and potentially impactful. Fusion energy would be a long-envisioned source of firm, safe, carbon-free electricity whose successful development requires creative, innovative cryogenic engineering.

Fusion power plants use high temperatures and pressures to create the conditions found in stars in which light atoms such as hydrogen fuse and produce helium and enormous amounts of energy that can be converted to drive generator turbines. One leading approach, being pursued by MIT spinout Commonwealth Fusion Systems (CFS), leverages the powerful fields of HTS-based magnets to create a "star in a bottle" capable of

containing and managing a steady-state plasma; the company's SPARC device aims to be the first system to achieve net energy from magnetically confined fusion and a proof of concept for subsequent commercialization.

*"One of my colleagues used the term 'just-in-time engineering'; a lot of work happens in parallel in order to accelerate the timeline to get SPARC operational as soon as possible," says Adam Weiner, Cryogenics Lead for SPARC*

SPARC has several operating modes that pose a wide range of cryogenic requirements and duty cycles. These include steady-state static

loads, elevated loading during multiday high temperature cleaning processes and, most demanding of all, the peak dynamic loads associated with an intensive daily schedule of fusion pulses that will begin after expected commissioning in 2025.


These pulses create as much heat as a small commercial power plant. SPARC is not designed to produce electricity, so instead of being sent to a generator, the heat must be removed by the cooling systems.

Some of the system's HTS components require cooling to 8 K and some to 15 K; other non-HTS elements require 80 K. Many design aspects of SPARC are still being finalized, so requirements can be imprecise and subject to change. CFS operates in an especially urgent environment because of fusion energy's potential as a game-changing technology to mitigate climate change.





Simplified layout of the major cryogenic system equipment. Credit: Commonwealth Fusion Systems



Rendering of the cryogenic plant installed within the utility building. Credit: Commonwealth Fusion Systems

“One of my colleagues used the term ‘just-in-time engineering’; a lot of work happens in parallel in order to accelerate the timeline to get SPARC operational as soon as possible,” says Adam Weiner, Cryogenics Lead for SPARC, who worked for over a decade at the Fermi National Accelerator Laboratory.

To meet these challenges, the SPARC cryogenics team is building a unique cooling plant and distribution system using supercritical helium coolant, which offers better thermodynamic efficiency and simpler single-phase heat transfer than liquid helium. Two main compressors provide redundancy, while an architectural combination

of series and parallel turbines delivers operational flexibility.

But the system’s most distinctive element is its blowdown system, which handles the intense dynamic fusion-pulse cooling loads. Described by Weiner as a “cryogenic rocket engine,” it’s

► continues on page 10

capable of delivering a short-term burst of coolant to SPARC's toroidal field (TF) magnets for total equivalent cooling power of 2.9 MW over 10 seconds.

The team initially envisioned handling pulse cooling with a large pump, cold buffer and cold/warm expansion vessel, but instead opted for tanks pre-filled with 8 K helium pressurized up to 20 bar. During a pulse, peak flow of over 200 kg/s passes through the TF magnets and into recovery tanks. Re-cooling of the helium takes about four hours — fast enough to support the planned schedule of four high-power pulses per day.

Weiner notes that the tank-based blowdown strategy has made it easier to adapt to changes in flow requirements as SPARC's design has evolved. "Also, our site isn't that big, so we appreciate being able to use the tanks to store helium inventory."

Additionally, 100% of the cryoplant cooling capacity can be quickly delivered if needed to protect SPARC's TF magnets from serious damage.

A powerful enabler for the SPARC cryo work has been effective collaboration with supplier companies. "There's a lot of excitement among their technical teams, and they've worked with us very well, despite us pushing hard and asking them to do things they're not used to, like designing while building," says Weiner. "The fast pace of our procurement cycle can be tough, but it does result in quicker payment and project turnover, which we hope is good for their businesses."

CFS's roadmap envisions SPARC's successor, ARC, being the first on-grid fusion power plant by the early 2030s, followed by rapid commercial uptake. Cryogenics is playing a pivotal role in that endeavor and ultimately in decarbonization of the world's electrical supplies. [www.cfs.energy](http://www.cfs.energy)



**Commonwealth Fusion Systems has more than 500 employees from a variety of disciplines working together to build SPARC.**  
Credit: Commonwealth Fusion Systems



**The SPARC facility on the Commonwealth Fusion Systems campus in Devens, Mass. will house the SPARC tokamak, which will demonstrate commercially relevant net energy from fusion for the first time in history.** Credit: Commonwealth Fusion Systems

**Cryogenic Treatment Database**

A leading resource for research and information in the field of cryogenic treatment—the use of extremely cold temperatures to improve the properties of materials.

<http://2csa.us/ctd>

# Can LH<sub>2</sub> Preserve Our Last Clean Continent?

by Yulia Gitter, Graduate Research Assistant, HYPER Center at Washington State University; and Liam Turner, Fulbright scholar, Monash University

Antarctica is vital for cold research, from understanding our fragile climate to tracking local fauna. Energy is critical to this research as it supports expeditions and heating bases. Reliance on diesel import is leaving a dark legacy on the continent, as the buildup of black carbon is causing accelerated rates of animal birth defects and melting ice shelves.<sup>[1,2]</sup> We must transform our Antarctic fueling practices with urgency if we are to preserve our last clean continent.

Liquid hydrogen (LH<sub>2</sub>) can offer a reimagining of clean Antarctic energy, with its versatility for import or onsite production to power bases and vehicles through combustion and fuel cells. Like diesel, LH<sub>2</sub> must undergo similar adaptations to withstand the harsh, isolated conditions of Antarctica. Adopting LH<sub>2</sub> will require an assessment of potential end-use technologies for enhanced research and an economic assessment of energy supply pathways. As a student team across Monash University, Australia, and the HYPER Center at Washington State University, we explored the potential of LH<sub>2</sub> for Australia's largest Antarctic base, Mawson Station.

## Technology Assessment

Any Antarctic technology must advance the Australian Antarctic Division's (AAD) commitment to enhancing environmental research while minimizing the footprint of operations. Green LH<sub>2</sub>'s high gravimetric energy density could enable the use of near-silent fuel cell-powered unmanned aerial and submersible drones (UAV, UUV) for long duration surveying. A semi-quantitative assessment was conducted to identify the opportunities and challenges of adopting both technologies for Antarctic research. Factors considered ranged from technology readiness, performance in Antarctic conditions, safety, and perception by researchers. The major opportunities and challenges are highlighted in Table 1.

The assessment showed green LH<sub>2</sub> could cut carbon and improve Antarctic research. Small-scale demonstration of LH<sub>2</sub>-fueled UAVs is possible by utilizing existing infrastructure. However, larger-scale LH<sub>2</sub> energy adoption would require personnel training and a larger supply chain.

## Economic Assessment

Mawson annually imports 900,000 liters of diesel, costing \$5 million AUD and 2.5 million metric tons of CO<sub>2</sub>.<sup>[3]</sup> Economic studies assessed the

Technology Assessment Criteria	Opportunities and Challenges for Hydrogen UAV/UUV Adoption in Antarctica.
Technology Interest	Interviewed AAD personnel expressed high interest for adopting LH <sub>2</sub> -powered UAVs to expand Antarctic research.
Ease of Implementation	Electrolysers that are already used for inflating weather balloons could refuel UAVs. Recovering fuel cell heat would likely be required to moderate drone temperature.
Technology readiness	Hydrogen-powered UAVs and UUVs were undergoing technology demonstration level at the time of study. Demonstrating extended use for reliability will be critical for Antarctic adoption.
Skills Requirements	Two trained professionals would likely be required for UAV refueling and operation. AAD staff would require hydrogen training due to limited onsite personnel capacity.

Table 1: Analyzing hydrogen-powered UAV/UUV adoption via Antarctic interviews and criteria. Credit: Gitter and Turner




Figure 1: 18-year trends comparing current diesel usage and scenarios for LH<sub>2</sub> energy transition. Credit: Gitter and Turner

cost of transitioning Mawson's energy supply from diesel to LH<sub>2</sub> import by considering the OpEx of liquefaction and shipping with the CapEx of storage tanks. AAD historical records indicated 65,000 kg/year of LH<sub>2</sub> would be required to substitute current diesel use. Importing LH<sub>2</sub> from S.E. Australia would incur a 3x shipping cost multiplier on top of an assumed production cost of \$5 AUD / kg LH<sub>2</sub>. The long-term costs of LH<sub>2</sub> adoption were quantified by considering the following energy supply scenarios:

100% diesel use continued; 100% immediate transition to imported H<sub>2</sub>; installing a second wind turbine and import H<sub>2</sub> for firming; a gradual increase to 100% H<sub>2</sub> use over a 15-year period; and installing a second wind turbine and increase H<sub>2</sub> use over a 15-year period.

Figure 1 indicated that LH<sub>2</sub> import coupled with renewable generation would be more cost-effective than diesel in the long run. Further work is required to quantify the relative costs of energy to supply base power, heating and equipment and how on-site LH<sub>2</sub> generation scenarios with renewables could compare on cost.

Resolving the potential for LH<sub>2</sub> to advance researchers' commitment to minimize the environmental footprint of exploration will require further techno-economic modeling of on-site production and use scenarios. Expertise sharing on liquid hydrogen technology performance and personnel requirements for deployment will be critical in building the foundation for liquid hydrogen-fueled research. Antarctica is our world's most fragile natural environment, but it has the potential to be a sustainability role model for the rest of our world. HYPER Center and Monash are continuing this work, and expertise sharing from the nexus of cryogenic engineers could accelerate Antarctic liquid hydrogen adoption. [yulia.gitter@wsu.edu](mailto:yulia.gitter@wsu.edu).

## References

- [1] Cordero, R. R., Sepúlveda, E., Feron, S., et al. (2022). Black carbon footprint of human presence in Antarctica. *Nature Communications*, 13, 984.
- [2] Fretwell, P. T., Boutet, A., & Ratcliffe, N. (2023). Record low 2022 Antarctic Sea ice led to catastrophic breeding failure of emperor penguins. *Communications Earth & Environment*, 4, 273.
- [3] Australian Antarctic Division. (n.d.). Australian Antarctic Program. Australian Antarctic Division.

# H2FLY Pioneers Emissions-Free Flight with Successful Liquid-Hydrogen-Powered Aircraft

by Rachel McDonald and Libby Adam, H2FLY

Stuttgart-based innovator H2FLY has achieved an unprecedented breakthrough in aviation history by successfully conducting the world's first piloted flight of an electric aircraft powered by liquid hydrogen. This remarkable milestone marks a pivotal moment in the journey towards sustainable aviation, showcasing the immense potential of hydrogen-based technology in revolutionizing the industry.

## Technological Advancements in HY4 Aircraft

The HY4 aircraft's propulsion system stands as a testament to cutting-edge engineering. It harnesses the power of a hydrogen-electric fuel cell system founded upon advanced low temperature PEM technology. This system's resilience is underscored by the presence of four redundant systems, ensuring unparalleled reliability even under low pressure conditions, maintaining functionality at a minimal 0.35 bar absolute.

Integral to the aircraft's operation is the cryogenic storage of liquid hydrogen, facilitated by a meticulously designed multilayer vacuum insulated dewar tank. Extracting hydrogen for the fuel cell system involves an intricate water-glycol evaporator mechanism, optimizing the evaporation of liquid hydrogen for efficient utilization in the aircraft. Stringent safety protocols in place adhere rigorously to industrial and aviation standards, ensuring the secure and safe handling of cryogenically stored liquid hydrogen during all phases of flight.

## Performance Metrics and Environmental Impact

The adoption of liquid hydrogen as the aircraft's power source presents a substantial leap in performance. This innovative technology effectively doubles the range of the HY4 aircraft to an impressive 1,500 km, surpassing the limitations associated with gaseous hydrogen. Beyond its enhanced performance, the hydrogen-electric propulsion system boasts zero emissions during flight, contributing solely water vapor and significantly reducing the aviation industry's carbon footprint.



The HY4 can seat up to four fliers and has a range of 932 miles. Credit: H2Fly

## Industry Impact and Future Trajectory

H2FLY's groundbreaking achievement serves as a catalyst, propelling the aviation industry's collective efforts towards carbon emission reduction. Aligned with global environmental sustainability objectives aiming for net-zero emissions by 2050, this technological advancement serves as a cornerstone for transformative change in aviation.

The vision forward for H2FLY encompasses the strategic scaling of this pioneering technology, envisaging its integration into regional aircraft and diverse aviation applications. The company's unwavering focus remains on developing robust fuel cell systems, aimed at enabling emissions-free commercial flights and spearheading a sustainable aviation revolution.

## Collaborative Endeavors and Key Partnerships

The success story of the liquid hydrogen-powered flights owes its realization to collaborative efforts with esteemed partners including Air Liquide, the German Aerospace Center (DLR), EKPO Fuel Cell Technologies, Fundación Ayesa and others. These partnerships, bolstered by support from European government funding and various

ministries, have been instrumental in accelerating the progress of hydrogen-powered flight.

## Pathway to Commercialization and Industry Transformation

H2FLY's ambition to commercialize hydrogen-electric aircraft by 2027 signals a transformative shift in the aviation landscape. The potential commercial availability of these aircraft would provide airlines and passengers access to revolutionary, sustainable air travel options, heralding a new era in commercial aviation. The successful completion of flight testing in Project HEAVEN signifies a critical stride towards realizing emissions-free, medium- and long-haul commercial flights. H2FLY's relentless commitment to innovation and sustainability positions them at the forefront of reshaping the future of aviation.

The groundbreaking liquid hydrogen-powered flights conducted by H2FLY represent not just technological achievements but herald a paradigm shift towards a more sustainable future for air travel. H2FLY's pioneering strides in hydrogen-based aviation technologies lay the groundwork for a cleaner, greener and more efficient era of aviation, setting new standards and inspiring worldwide transformation in the skies. [www.h2fly.de](http://www.h2fly.de)



# Zirnox

Thin Film Cryogenic Thermometer

## Key Features

- Widest Temperature Range of Any Cryogenic Thermometer
- Fast Thermal Response
- Low Magnetic Field-Induced Errors
- 0.02K to 450K Calibration Available
- Micro Hermetic Package Available Soon




# Si540

## Silicon Diode Cryogenic Thermometer

## Key Features

- Standard Temperature Range 1.4K to 450K
- Interchangeability
- Excellent Repeatability
- Robust/Reliable Packaging
- New High-Temp/UHV Compatible Version Available (Up to 500K)



[scientificinstruments.com](http://scientificinstruments.com)

[sales@scientificinstruments.com](mailto:sales@scientificinstruments.com) • (800) 466-6031

# LCLS-II's 'First Light' Revolutionizes X-ray Science

by Eric Fauve, Cryogenic Division Director, SLAC National Accelerator Laboratory, with components attributed to Ali Sundermier



LCLS-II compressor skids. Credit: TJNAF

The LCLS-XFEL at SLAC National Accelerator Lab has launched its upgraded version, LCLS-II, generating its first X-rays. This advancement is set to revolutionize research, offering unparalleled capabilities for studying quantum materials with remarkable precision. Scientists worldwide are queued up to explore various applications, from improving computing and communication technologies using quantum materials to understanding fleeting chemical reactions for sustainable industries and clean energy. Additionally, the upgrade enables investigations into biological molecules' functions for pharmaceutical advancements and opens doors to entirely new scientific realms by studying the world's fastest timescales.

"This achievement marks the culmination of over a decade of work," said LCLS-II Project Director Greg Hays. "It shows that all the different elements of LCLS-II are working in harmony to produce X-ray laser light in an entirely new mode of operation."

Reaching "first light" is the result of a series of key milestones that started in 2010 with the vision of upgrading the original LCLS and blossomed into a multiyear billion-dollar project involving thousands of scientists, engineers and technicians across DOE, as well as numerous institutional partners.

## Accelerator

The superconducting linear accelerator (Linac) relies on cryogenic cooling to hit temperatures close to absolute zero, around 2.0 K. This

temperature allows niobium, a vital material for RF (radio frequency) cavities, to lose all electrical resistance, significantly cutting down energy loss during acceleration and boosting efficiency. By keeping the cavities at 2.0 K, they operate below niobium's critical temperature, enabling superconductivity and high accelerating gradients with minimal energy loss, unlike copper-based accelerators. Liquid helium in cryogenic cooling maintains the cavities at this critical temperature for optimal performance.

At SLAC's LCLS-II, running both the superconducting and copper-based accelerators in tandem is groundbreaking. The copper accelerator operates at higher energies, complementing the superconducting one by providing beams with different features such as higher energy levels and intense X-ray pulses. Cryogenics is pivotal in enabling the superconducting accelerator for continuous-wave (CW) operation, vastly broadening the spectrum of possible experiments.

## Cryomodules

The cryomodules used in the LCLS-II project are a marvel of engineering, designed with high-purity niobium for the superconducting RF (SRF) cavities. These superconducting cavities operate at remarkably low temperatures, around 2.0 K. The 1.3 GHz cryomodules house eight 9-cell SRF cavities cooled with superfluid helium at this critical temperature, enabling their efficient operation and exceptional performance. "The collaboration between Fermilab, Jefferson Lab and SLAC was pivotal in the successful design and construction

of the cryomodules. Fermilab's expertise in engineering cryomodules, coupled with Jefferson Lab's contributions in manufacturing a significant portion of these modules, was essential in bringing LCLS-II to fruition," remarks LCLS-II-HE Project Technical Director Marc Ross.

## Cryoplant, Infrastructure and Process

The cryogenic system at LCLS-II operates through a complex infrastructure featuring two large helium cryoplants delivering substantial cooling power. Each cryoplant comprises a 4.5 K refrigerator coupled with a 2.0 K system capable to deliver 4.0 kW of isothermal refrigeration at 2.0 K. The 4.5 K refrigerators use oil-flooded screw compressors, liquid nitrogen pre-cooling and four stages of cryogenic turbo-expander to produce liquid helium. The 2.0 K system consists of a train of five cryogenic compressors allowing the cavities to operate at 31 mbar and 2.0 K. The supporting infrastructure includes a 1,900-square-meter building, housing the critical cryoplant's gear and necessary systems. An electrical switchyard delivers the 10 MW required to power the screw compressors, and five cooling towers deliver the 1,200 m<sup>3</sup>/h required to evacuate the compression heat.

## Commissioning and Operation

The LCLS-II Linac's commissioning began with a systematic cooling-down process in March 2022, carefully considering cooling speed, gradient and cryoplant capacity. Remarkably, within just five days, the cool-down was achieved, a significant



Transfer lines and distribution boxes Credit: SLAC

milestone in the project. Designed for year-round operation, the LCLS-II allows weekly maintenance called Planned Accelerator Maintenance (PAM), lasting 1 to 3 days for Linac maintenance, excluding cryopant shutdowns or Linac warming. Until mid-2026, the cryopant is expected to run continuously, pausing Linac operations for about a year to install 23 additional cryomodules for the LCLS-II HE (High Energy) Project.

Beyond 2027, the two cryopants will support the LCLS-II HE Linac. Major cryopant maintenance will then happen every three years or longer. During maintenance, the Linac will be supported at reduced capacity by a single cryopant, ensuring continual operation of the cryogenic components.

## Safety and Operation

Safety measures in the LCLS-II project focus on cryogenic operations, tackling risks like pressure hazards, cold gas exposure and potential oxygen deficiency. The engineering design meets ASME pressure codes, ensuring safety. All gas relief (vents and relief valves) are connected to exhaust pipes routed outside buildings to reduce oxygen deficiency hazard (ODH). All buildings are equipped with oxygen sensors connected to an oxygen deficiency monitor that will alarm if oxygen level decreases. SLAC maintains strict safety protocols for high voltage and industrial safety. Also automation and machine protection interlocks are widely implemented for efficient and safe operation.

## Impact

LCLS-II signifies a pivotal leap in X-ray science. It enables scientists to capture atomic-scale



The launch of its upgraded version, LCLS-II, at SLAC National Accelerator Lab marks a groundbreaking advancement, generating its inaugural X-rays and promising a revolutionary leap in research with unparalleled capabilities for studying quantum materials with remarkable precision. Credit: SLAC

details of molecules, atoms and electrons in unprecedented ways. "This upgrade to the most powerful X-ray laser in existence keeps the United States at the forefront of X-ray science, providing a window into how our world works at the atomic level," Secretary of Energy Jennifer M. Granholm notes. While Asmeret Asefaw Berhe from the DOE praises its potential impact on fundamental science, clean energy and national security through quantum information science. "I really look forward to the impact of LCLS-II and the user community on national science priorities," she adds.

The profound impact of LCLS-II spans diverse scientific domains. Its capabilities promise breakthroughs in quantum materials, ultrafast computing, sustainable manufacturing and

materials science. By capturing atomic-scale snapshots of reactions and creating 'molecular movies,' LCLS-II will revolutionize understanding in biology, chemistry and physics, attracting researchers globally for a wide array of experiments in the near future. Director Mike Dunne emphasizes that this facility, offered at no cost to users, is set to drive a revolution across academic and industrial sectors, ushering in a wave of innovation and discoveries. "Experiments in each of these areas are set to begin in the coming weeks and months, attracting thousands of researchers from across the nation and around the world. LCLS-II is going to drive a revolution across many academic and industrial sectors. I look forward to the onslaught of new ideas – this is the essence of why national labs exist." [www6.slac.stanford.edu](http://www6.slac.stanford.edu)

# Elevating Pipe Support Systems with “Lift-Off” Innovation


by Martin Schutte, Lift-Off Pipe Supports

One often underappreciated hero in the field of industrial piping plays a pivotal role – pipe supports. These unassuming components are tasked with the vital responsibility of ensuring that piping systems remain stable, safeguarding against overloading and the undue stress that could lead to catastrophic failures in the overall system. Pipe supports come in various forms, including hangers, struts, pick-ups, springs, beams and more. Without these critical elements, the operation of any industrial plant would teeter on the edge of instability. However, the history of pipe supports has been marred by a series of failures stemming from issues such as corrosion, excessive deflection and inadequate design considerations.


## Common Faults and Standards

Various types of failures can affect pipe support systems. Corroded supports, resulting from the corrosion of structural steel, can undermine their load-bearing capacity, impacting the entire system. Excessive structural deflection occurs when support beams or columns deteriorate over time, leading to inadequate load-carrying capacity and compromising the system's integrity. Wall thickness degradation can happen due to wear and tear, causing pipe walls to fail under stress and poses significant safety risks. Vibrations and oscillations, whether from rotating machinery or external factors like wind, can create stress fractures in pipes, threatening system integrity. Pipe support failures can stem from incorrectly specified elements that degrade under environmental and operating conditions. Additionally, process failures may occur if industrial process conditions are not adequately considered during the initial design phase. Incorrect installation of pipe supports, subsidence of foundational supports and other issues can also lead to unforeseen complications and failures.

To ensure the reliability of pipe support systems, certain requirements must be met. These include considering process conditions, such as design temperatures and pressures, as well as external factors like slug flow and corrosive atmospheres. Evaluating climatic conditions, such as wind strength, seismic activity, and corrosive atmospheres, is crucial. In cases near urban areas,



**Loading the pipe across the full beam flange width was crucial. Supporting it differently led to stress increases of over 100% in simulations.** Credit: Lift-Off Pipe Supports



**Lift-Off Pipe Supports tested various models and supports, confirming their strength. The ultimate design, including polymer supports, proved effective even under 550-pound stress.** Credit: Lift-Off Pipe Supports

noise and acoustic requirements may necessitate additional insulation. Cathodic isolation may be needed to prevent corrosion, and supports must be fire-resistant to avoid contributing to the spread of fire events.

Moreover, the supports must meet specific criteria. They need to be adaptable for various applications, including guides, line stops and spring supports. Corrosion resistance is crucial to withstand highly corrosive atmospheres, and supports must be compatible with both high and low temperatures, including cryogenic conditions. A variety of materials should be used to allow flexibility and customization. Effective drainage capability is necessary to prevent damage in corrosive atmospheric conditions. Additionally, supports must be designed,

manufactured and tested to withstand both static forces and shock loads, as specified or determined on-site. Lastly, compliance with relevant piping requirements and industry codes is essential to ensure safety and reliability.

## Production

During the development of “lift-off” pipe supports, extensive research focused on materials, manufacturing techniques, standards, codes and compliance regulations to meet high performance and reliability standards. One critical insight was the need for even load distribution across support beams to avoid stress concentrations and eccentric loads. Addressing friction between pipes and support beams led to an innovative non-slide compound that eliminated the need for additional

► continues on page 18





# Moving you ahead.

Gardner Cryogenics is a world leader in the storage and transport of liquid hydrogen and helium. We help you move and store molecules with near-zero loss.

## **UNIQUE TECHNOLOGIES**

Gardner's leading-edge technologies provide the lowest heat-leak for the longest hold times and highest yields. Our liquid helium and liquid hydrogen distribution systems are the most reliable, safest, and most efficient in operation.

## **WORLD-CLASS MANUFACTURING**

Gardner manufactures the world's safest, most reliable containers and vacuum lines. We are ISO 9001 certified and have extensive experience with extreme cryogenics.

## **PROVEN PERFORMANCE**

Gardner has produced over 1800 tanks and containers, and our first container is still in operation. We operate the most liquid hydrogen transport equipment in the world.

## **RESPONSIVE SERVICE**

Gardner specializes in world-class container rehab, transport damage repair, modifications and upgrades, and vacuum reconditioning. We adhere to worldwide code standards.

At Gardner, we reach beyond mechanical production into the realm of technical artistry, elevating our technology into a class by itself.



**GARDNER  
CRYOGENICS**

gardnercryo.com • 610-266-3700  
gardnsa@gardnercryo.com

fixtures, reducing the risk of corrosion and failure. The development phase included multiple models, process assessments and finite element analysis (FEA) studies to ensure safety and performance. Two key variants, "lift-off vertical" (LOV) and "lift-off rest" (LOR) supports, were rigorously tested and demonstrated the effectiveness of load distribution. The "lift-off" family also includes composite resin supports that resist loading, corrosion, UV rays and fire. Their material flexibility allows them to be tailored to specific project requirements and environmental conditions.

Manufacturing is done in-house with stringent safety and quality control measures. The facility's strategic location in Lake Charles, Louisiana, near the Gulf of Mexico, is ideal for the oil and gas industry. Every support batch undergoes comprehensive testing and documentation as part of the quality program. Regarding installation and safety, clients receive a thorough understanding of the risks associated with installing pipe supports, with a focus on safety and necessary precautions in live plant environments. Training for tradesmen and contractors minimizes incidents, ensuring personnel safety and system integrity.

## Looking Ahead

The introduction of the "lift-off" pipe supports marks a significant step forward in the world of industrial pipe support systems. The "lift-off" supports have proven to be a reliable and robust alternative, capable of withstanding a wide temperature range, from -270 °F to +450 °F, with intermittent temperature spikes reaching up to 550 °F. Moreover, they exhibit excellent UV and corrosion resistance, making them well-suited for the demanding conditions of industrial settings. The even distribution of load across beam flanges, rather than concentrating on back mark offsets, has significantly increased the beam carrying capacity, enhancing overall safety and performance.

"Lift-off" pipe supports have emerged as a pioneering solution that addresses the historical failures and multifaceted challenges associated with traditional pipe supports. With unwavering commitment to quality, safety and performance, these innovative supports are poised to make a transformative impact in the industrial piping landscape. [www.liftoffpipe.com](http://www.liftoffpipe.com)

# ASK THE EXPERTS

Get expert advice.  
Find answers.

Submit a  
tech question.

<http://2csa.us/experts>

## COOLING SYSTEMS FOR SUPERCONDUCTIVE DEVICES

System concepts for AC and DC cables, magnets, FCL and rotating machines



**STIRLING  
CRYOGENICS**

- Cooling in 20 to 90K range by GHe flow
- Cooling in 67 to 90K range by sub-cooled LN<sub>2</sub>
- Adjustable cooling power
- Turn-key systems including VJ pipe work and valving
- More than 70 years of experience

### Stirling Cryogenics

Headquarters: The Netherlands

Newly opened: USA Office

[www.stirlingcryogenics.com](http://www.stirlingcryogenics.com)

[info@stirlingcryogenics.com](mailto:info@stirlingcryogenics.com)



CLEAN ENERGY SOLUTIONS

a DOVER company



**Vacuum Jacketed Pipe (VJP)**  
The most cost-effective way to transfer cryogenic liquids

**Evacuation & Safety Device**

The comprehensive component design to complete the system design, manufacture, and installation capability.



**Stainless Steel Inner Pipe**

Maximum service life thanks to these advanced features to produce exceptional efficiencies across the entire system.

Cryogenic insulation for Nitrogen, Oxygen, Argon, Helium, Natural Gas, Carbon Dioxide, Hydrogen

**Super-Insulation**

The inner and outer pipe is constructed of 300 series stainless steel. Insulation is a low vacuum with multiple layer insulation (MLI).



For more information on the Vacuum Jacketed Pipe scan the QR Code above



**CryoMac® 4 LNG Fueling Nozzle**  
Maximum safety for LNG fuel technology



**SAFE**

"Safety Stop" for added safety and operator protection.

**DURABILITY**

Ball cage interface with receptacle adapter ring guides and locks the nozzle in place for optimum engagement and user interface to increase environmental seal life.



Patented nozzle safety feature is recognized in the market as a major failsafe advantage for the operator.



For more information on the CryoMac 4 scan the QR Code above

# Cryogenics Drives Advancements in Aerospace Welding

by Carlo Chatman, Tri Tool Representative

The aerospace industry is continually advancing, which is creating a demand for higher precision and durability in every component used. Among these critical elements, piping and tubing systems stand out as essential conduits for vital gases and liquids within spacecraft, aircraft and launch pad infrastructures. Working with these systems, however, poses substantial challenges, especially when it comes to welding.

The meticulous process of aerospace welding demands precision in preparing pipe and tube ends to exceedingly tight tolerances. It requires avoiding the introduction of contaminants and achieving specified surface finishes. As the industry shifts towards lighter, stronger materials like Inconel and other nickel superalloys to improve efficiency and reduce weight, the challenges escalate. These materials must withstand extreme conditions, including cryogenic temperatures, high pressures and intense environmental stresses. Inconel, a highly resistant alloy widely used in aerospace due to its robustness in high-temperature environments, presents a formidable challenge for machining. Its toughness makes it exceptionally hard to shape and work with, often causing tools to break or deform during machining processes.

"Aerospace companies are pushing the boundaries of what can be achieved every day. As a result, they are utilizing more advanced materials for piping and tubing, often with smaller diameters, thicker walls and more complex joint geometries than even ten years ago," says Chris Belle, CEO of Tri Tool Technologies. "The more inconsistent the machining, the more weld failures you will have. Unfortunately, materials such as Inconel only increase the chances of joint misalignment, poor prep angles and contamination," explains Belle.

"To minimize or eliminate weld failures for these critical applications, the key is achieving very consistent, high-quality weld prep every single time," continues Belle, who underscores the criticality of getting the weld prep right on the first attempt, especially when considering the expense of advanced alloys. Understanding these materials' properties and limitations is pivotal for machinists, who often require




*In tight spaces, field machinists can rely on the 300STS—a compact, portable squaring tool. Its precision and lightweight build streamline operations, ensuring accurate cuts and boosting productivity. Credit: Tri Tool Technologies*

specialized cutting and facing equipment tailored for these demanding applications.

The aerospace industry relies heavily on semi-automated orbital welding machines for their ability to produce reliable, high-quality welds meeting stringent criteria. However, achieving precise welds demands immaculate pipe and tube end preparations with no room for error, necessitating tools that guarantee proper fit and alignment.

Tri Tool Technologies addresses this need with products like the 300STS, offering precision cuts within a remarkable range of tube sizes and wall thicknesses. The company's emphasis on tool bit quality underscores its commitment to precision and durability, which is critical for aerospace applications where thousands of preps per week are commonplace. Moreover, the company's ability to customize solutions based on client requirements adds immense value. Recent modifications to Tri Tool's

equipment, such as introducing miter cuts and proprietary cutting bits tailored for Inconel, highlight its adaptability and commitment to meeting evolving aerospace demands.

Tri Tool's innovative solutions have significantly impacted the aerospace sector, aiding in the acceleration of production timelines for launch vehicle platforms and solving intricate welding challenges in critical components like diffuser nozzles. As the aerospace landscape continues to evolve with the rapid expansion of private space companies and the development of next-generation aircraft, the necessity for precise, reliable, and adaptable machining solutions becomes increasingly evident. Tri Tool Technologies stands at the forefront, offering aerospace-specific pipe and tube squaring solutions that ensure weld integrity under the most demanding conditions. Its dedication to innovation and precision underscores its role in advancing aerospace welding technology. [www.tritool.com](http://www.tritool.com) 

# INDUSTRY EXPERIENCE & EXPERTISE

CPC-Cryolab continues to design and manufacture world class cryogenic and industrial gas equipment with the highest standards for clean alternative energy sources. As part of the MEC family, we will continue to lead the industry with modern designs and manufacturing practices, providing highly engineered, long term solutions upheld by the highest standards for performance and safety with an even stronger commitment to customer service and innovation.



hydrogen energy



space exploration



semiconductor industry



superconductivity



subatomic particle acceleration

**CPC-Cryolab**  
an MEC company

4430 East Adamo Dr. Suite 305, Tampa, FL USA 33605  
Phone +1 (813) 644-3764  
sales@cpc-cryolab.com | www.cpc-cryolab.com

© CPC-Cryolab. All Rights Reserved 2021

# Calling Women in Cryogenics and Superconductivity

Join us for our annual feature in *Cold Facts* as we honor the remarkable contributions of women in cryogenics and superconductivity. Seeking fresh perspectives and untold stories, we invite women who are yet to be included to share their insights.

Are you a trailblazer or know someone breaking barriers in these fields? Contact our editor, Anne DiPaola (editor@cryogenicsociety.org), to receive an applicant questionnaire. Return your responses and a headshot by January 26 to be featured in our March 2024 issue.

Help us widen the scope! Spread the word and encourage deserving women in cryogenics and superconductivity to step forward. Together, let's spotlight the innovation and impact of these remarkable individuals.

Your story matters. Join us in celebrating the brilliance of women shaping the future in cryogenics and superconductivity for generations to come!





**tf technifab**  
PRODUCTS

**WE PROVIDE SOLUTIONS**

SERVICE DESIGN ENGINEERING  
INSTALLATION MANUFACTURING

**tf technifab**  
SINGLE SOURCE ACCOUNTABILITY



**CONTACT US TODAY**

Phone: 812.442.0520  
Email: sales@technifab.com



**tf technifab**  
CRYOGENICS  
We Know Cryo®

www.technifab.com




**TEMPSHIELD®**  
CRYO-PROTECTION®



**Tempshield's Cryo-Gloves® for IQF mechanical or cryogenic food freezing**

info@tempshield.com

207-667-9696

TEMPSHIELD.COM



## CryoComplete

Everything you need to make temperature-dependent, low-level electrical measurements from **77 K to 500 K**



Complete measurement system



Optimized full signal path



Quick lead time

### PC with MeasureLINK™

Enables a wide range of capabilities, including data charting, instrumentation control, and system monitoring with a cryostat-specific process view.



### Source + measure + lock-in

Run ultra-low-noise AC/DC measurements with the MeasureReady® M81-SSM synchronous source measure system. It includes a balanced current source module and a DC/AC/lock-in voltmeter module with a combined noise performance (differential) of 4.1 nV/√Hz.

### LN<sub>2</sub> cryostat

The Environment by Janis VPF-100 sample-in-vacuum cryostat provides a variable-temperature sample environment from 77 K to 500 K. The pour-fill design allows quick and easy LN<sub>2</sub> refills.



### Temperature controller + sensor

Control temperature within 50 mK with our Model 335 temperature controller, precision calibrated diode, and a pre-wired heater. Default cryostat tuning enables fast setup and operation.

# ENABLING QUANTUM

Worldwide, scientists are racing towards multiple possible futures through the exploration of quantum technologies. Cryomech is proud to be the not-so-silent partner in enabling a plethora of quantum initiatives by powering dilution refrigerators with our PT310 and PT425 cryocoolers.



**60**  
YEARS  
**CRYOMECH**

**BLUEFORS**



315.455.2555 [cryomech.com](http://cryomech.com)





# Zero Resistance Zone

by Quan-Sheng Shu, Retired Senior Scientist, and Jonathan Demko, LeTourneau University

## Cryo-Engineering for SRF

### Fifty-Five Years of Inextricable Success

Superconducting Radio Frequency (SRF) cavities are vitally central to SRF accelerators, boasting a Q factor about  $10^5$  times higher than copper cavities and the capability to produce accelerating fields (Eacc) on an order of magnitude greater than copper in CW. In the 1960s, SRF cavities were delicate instruments used by pioneering scientists in several prestigious labs. Over the past 55 years, the synergy between cryogenics and SRF accelerators has consistently proven mutually beneficial and successful. Today, the landscape has evolved significantly, with potential markets for industrial electron beams reaching \$10 billion annually. Various SRF cavities mainly made from Nb (Figure 1)<sup>[1-2]</sup> are widely used in high energy physics, nuclear science, FEL, XFEL, synchrotron lights, computer chips, and medical and industrial applications.

### Theoretical Performance

Unlike DC applications, where a superconductor (SC) has zero electric resistance, SC in RF fields have a specific surface resistance ( $R_s$ ) and allow magnetic fields to penetrate their surface to a depth ( $\delta$ ). In the SRF cavity, Eacc runs along the central axis. Near the cavity wall magnetic fields H are parallel to the cavity surfaces, with the highest Hmax around the cavity's equator. Electric fields are vertical to the surfaces, with the maximum Emax near the iris. Simplified formulas below can be used to derive several theoretical cavity performances.

### Ideal (theoretical) $Q_0$ .

The power dissipated  $P_d$  is given by the integral of resistive wall loss over cavity surface.  $Q_0$  is the ratio of energy restored in the cavity ( $\omega U$ ) to the energy loss  $P_d$ . G-cavity geometry factor and determined by its shape only,  $\mu_0$  - permeability of free-space and  $\omega$  - frequency.

$$U = (\mu_0 / 2) \int H^2 dV$$

$$P_d = (Rs/2) \int H^2 dS$$

$$Q_0 = \omega U / P_d = G / Rs$$

$$R_{BCS} = D f^2 (e^{-17.87/T})$$




Figure 1. A- Low  $\beta$  Nb cavities,<sup>[1]</sup> B- TESLA style cavity, and C- Cavity in LHe vessel.<sup>[2]</sup> Credit: A. Lombardi et al. and C. Pagani

The  $R_s = R_{BCS} + R_{res}$ .  $R_{BCS}$  is the ideal minimum resistance by BCS theory.  $R_{res}$  depends on materials' purity, external H, etc. For example, a 9-cell TESLA cavity (Nb) has  $G=270$  at 1.8 K and 1.3 GHz:  $R_{BCS}=4.55n\Omega$ ,  $R_{res}=R_{H}(earth H) = 3.42n\Omega$ ,  $Rs=7.97n\Omega$ , so the ideal  $Q_0=3.4 \times 10^{10}$ . However, for a copper cavity at 300 K and 1.3GHz,  $Q_0(Cu)=3 \times 10^4$ .

### Ideal (theoretical) Eacc.

Currently, the Type II superconductor Nb is the most popular cavity material and has a magnetic quench field Hc2 about 2400-Oe at 1.8 K. Therefore, for this cavity, the ideal maximum Eacc is about 56MV/m, corresponding to the Hc2.

### Journey to Ideal Performance

$Q_0$  vs. E curves are the primary measure of SRF cavity performance. Ideally, the cavity's  $Q_0$  should remain constant as the accelerating field E rises, up to the magnetic quench field, as shown by the "ideal" green line in Figure 2. However, in practice, the Q vs. E curve falls below the ideal due to various factors. Thanks to advancements in cavity fabrication, including shape design, high RRR Nb, e-beam welding, BCP, and RF processing, issues related to multipacting and thermal breakdown in cavities have been successfully addressed. Consequently, Cavity Eacc ranged to 7-12 MV/m with  $Q \sim 10^{10}$

in the 1980s. This progress laid the foundation for SRF accelerator projects like KEK, HERA, LEP, and CEBAF.

However, as Eacc exceeds 10-15 MV/m, field emission (FE) becomes the primary limiting factor.<sup>[3-4]</sup> FE significantly reduces the cavity  $Q_0$  due to the exponential increase in electron currents from FE origins. Extensive studies at Cornell, Wuppertal, KEK, Jlab, and DESY aim to understand and mitigate FE to reach higher Eacc. Various cavity treatment techniques, including thermometer mapping, He-RF processing, high-T treatment with Ti protection, and HPP, have been employed. These efforts culminated in achieving the Eacc of about 30 MV/m at Cornell in 1989-90,<sup>[3,4]</sup> generally meeting the TESLA requirement, as depicted in Figure 2. These achievements have helped make significant progress at TESLA, Jlab, FLASH, SNS, and LEP-II.<sup>[5]</sup>

The emergence of the Q-disease presents new, serious challenges for SRF cavities after FE reduction. Fresh efforts involving the development of large/single crystals of Nb, EP, HPR, and mild-temperature treatments (up to 120 °C) have yielded impressive results. In 2017-18, researchers at FNAL achieved a milestone with an Eacc of 48 MV/m and a Q above  $10^{10}$ .<sup>[6]</sup> Since 2010, more XFELs and additional upgrades to SRF accelerators have been developed.

## SRF Cryomodules

The SRF cryomodules demonstrate seamless collaboration between cryogenic techniques and SRF cavities, playing a vital role in ensuring the success of SRF accelerators. The SRF cavity is cooled within a LHe-II container, thermally isolated from room temperature using MLI blankets and the low thermal conductance support system within the cryomodule vacuum. The cryomodule also serves as the hub for high RF power to the cavities, cryogen distribution, and technical data collection.

The TESLA Collaboration, led by DESY, initially aimed to develop a 20 km e-e- linear collider but faced financial constraints that halted the project. However, core technologies from TESLA have since advanced worldwide.<sup>[7]</sup> Figure 3 illustrates a partial section of the TESLA/ILC cryomodule,<sup>[2]</sup> which spans about 12 meters and houses eight SRF cavities. Thermal shields are used to reduce radiation heat, featuring 30-40 MLI layers at around 65 K and 10 MLI layers at approximately 2 K. The low thermal conductivity posts are anchored




Figure 2. Simplified Q-Eacc plots used to showcase a few historical performances of the best cavities. Precise scaling in references: Cornell<sup>[3]</sup> and FNAL.<sup>[6]</sup> Credit: Q. S. Shu et al. and A. Grassellino et al.




Figure 3. A mock-up of TTF3 style XFEL cryomodule.<sup>[2]</sup> Credit: C. Pagani.

at 50-65 K and 6 K. Each cavity has a sophisticated RF coupler for transferring high RF power to the cavity and a HOM coupler to extract unwanted RF fields. A large, cold He return pipe (HGRP, 300 mm) is necessary to minimize pressure drop and can also serve as the primary structural support for the module cold mass. Typically, a cryogenic unit consists of about 10 cryomodule strings, contingent on the specific cryogenic cooling system of the accelerator design.

## Cooling of SRF Cryomodules

To build an SRF accelerator, it is crucial to further improve SRF cavity cooling, which involves two key aspects: 1. Enhancing the quality factor ( $Q_0$ ) and improving heat transfer on the cavity surfaces to reduce Kapitza resistances. 2. Designing and developing a highly efficient cryogenic liquefier/refrigeration system capable of supplying sufficient LHe and cold He gas to cool the cavities and associated components in all cryomodules within the

► continues on page 80




Figure 4. Diagram of the CHL at ORNL.<sup>[9]</sup> Top of form. Credit: M. Howell et al.

accelerator. The measured static and dynamic heat loads of an XFEL cryomodule at 16.5 GeV operation are summarized as follows<sup>[8]</sup>: Static- 2K 6.1 W, 5/8 K 8 W, and 40/80 K 102 W. Dynamic- 2 K 7.2 W, 5/8 K 2 W and 40/80 K 32 W. These values are comparable with XFEL design.

The Spallation Neutron Source (SNS) at ORNL serves as another exemplary SRF accelerator, providing a 1 GeV, 2 MW beam for experiments. Its linac comprises over 80 SRF cavities (805 MHz) housed in a total of 23 cryomodules operating at 2.1 K. Figure 4 illustrates the central He liquefier as a highly automated and reliable system.<sup>[9]</sup> The CHL employs a group of cold compressors to force cold He vapors into the heat exchangers of the cold box.

## SRF Accelerator and Cryogenic System

SRF linear accelerators have diverse applications as “user” machines, such as proton linac (e.g., SNS and ESS), heavy ion linacs (like FRIB, ATLAS, ISAC-II), linac/ER-linac-based FELs (like FLASH, XFEL, Jlab-FEL/ERL), and future projects like Shanghai HRR-XFEL and the possible International Linear Collider (ILC). Due to space limitations, we will briefly discuss only two SRF accelerators. The European XFEL spans 3.4 km, reaches electron beams of about 18 GeV, and delivers X-rays from 0.25 keV up to 25 keV. It comprises 96 cryomodules (approximately 800 cavities with an average of over 25 MV/m and  $Q \sim 10^{10}$ ), operating at 1.3 GHz with a 10 Hz repetition rate. These cryomodules run at 2 K, cooled by a cryogenic system with a 4-stage set of cold compressors (CC) that compress the cold helium vapor from 2400 Pa to about 110 kPa at a



Figure 5. SRF accelerator in tunnel of European XFEL.<sup>[10]</sup> Credit: Reschke et al.




Figure 6. LCLS-II CHL system model.<sup>[11]</sup> Credit: R. Bhattacharya et al.

mass flow of up to 100 g/s. Figure 5 shows the XFEL in a tunnel with SRF cryomodules suspended from the ceiling and RF infrastructure on the floor.<sup>[10]</sup>

The Linear Coherent Light Source (LCLS-II) developed at the SLAC National Laboratory has 37 LINAC cryomodules operated at 2 K to accelerate a 4 GeV electron beam, generating hundreds of watts of intense X-ray laser light. The cryoplant includes two helium refrigerators, each with an equivalent 4.5 K cold box, 18 kW, and 2 K cold box 4 kW. Two five-stage cold compressors are used to compress the cold He vapors as shown in Figure 6.<sup>[11]</sup>

### References

[1] A. Lombardi et al., XX International Linac Conference, Monterey, CA, 1998

- [2] C. Pagani, 12th Workshop of SRF, Cornell 2005
- [3] Q. S. Shu et al., IEEE Trans. on magnetics, vol. 27, No. 2, 1991
- [4] H. Padamsee et al., PAC 1991
- [5] Q-S. Shu et al, Adv in Cryogenic Eng. Vol.43, 1998
- [6] A. Grassellino et al., FERMILAB-PUB-18-827-TD
- [7] Q-S. Shu et al., Design of advanced cryostats, CEC/ICMC-2023
- [8] R Ramalingam et al., 2022 IOP Conf. Ser.: Mater. Sci. Eng. 1240 012123
- [9] M Howell et al 2015 IOP Conf. Ser.: Mater. Sci. Eng. 101 01212 90
- [10] Reschke et al, SRF2017, Lanzhou, China
- [11] R. Bhattacharya et al, 2020 IOP Conf. Ser.: Mater. Sci. Eng. 755 012121

## Hydrogen Getters for Cryogenic Vacuum Insulation



No activation required and no moisture generated! Vacuum Energy Getters ensure vacuum insulation lifetimes with outstanding performance and reliability (PG-HT-CRYO™ >250cc/g H<sub>2</sub> capacity)

For more information please contact us:

Email: [info@vacuumenergyinc.com](mailto:info@vacuumenergyinc.com)


Tel +1(216) 991 7000

[www.vacuumenergyinc.com](http://www.vacuumenergyinc.com)

"Exceptional Solutions for Exceptional Reliability"



## AMERICAN MAGNETICS




50+ years of experience  
Specializing in Cryogen Free & Custom Systems  
Recipient of 2009 R&D 100 Award  
15 month warranty on any system

[www.americanmagnetics.com](http://www.americanmagnetics.com)

(865)482-1056 • 112 Flint Rd., P.O. Box 2509, Oak Ridge, TN 37831

# design+innovation

- ADR Cryostats • pcSQUID™ Readout Electronics
- LTS and HTS dc SQUIDS • Cryogenic Cable Assemblies
- Mr. SQUID® Demonstration System • Foundry Services
- Superconducting Flex Cables



## STAR CRYOELECTRONICS

Superconductor Technologies for Advanced Research

505-424-6454 [info@starcryo.com](mailto:info@starcryo.com)

[www.starcryo.com](http://www.starcryo.com)

# White Paper Explores Gas Monitoring in Food Storage Safety

by Emily Mahlon, CO2Meter, Creative Director

Gas monitoring in frozen food storage plays a pivotal role in maintaining employee safety, food integrity and overall quality. The use of refrigerants or gases in these facilities necessitates constant monitoring to swiftly detect leaks, as certain gases pose severe health risks and potential fatalities if leaked into storage areas. Continuous monitoring, using gas detection safety systems, serves as a crucial preventative measure, averting exposure to harmful gases. Additionally, adherence to regional regulations on gas storage and handling is facilitated through effective gas monitoring, averting potential legal complications.

In CO2Meter's endeavor to highlight the significance of gas safety in frozen food storage, it aims to educate and raise awareness about the inherent hazards associated with handling compressed gases in the food industry. While preserving, storing and freezing are all fundamental processes, so is protecting employees from the gases involved and ensuring everyday facility safety. In response, CO2Meter published a white paper, "The Benefits of Gas Monitoring in Frozen Food Storage, Preservation, and Freezing," which focuses on elucidating the role of gases in food preservation, identifying potential hazards, and emphasizing the necessity of gas detection safety systems. Key takeaways of the white paper include understanding the role of gas in the frozen food industry; deciphering the use of gas across food production applications; identifying gas hazards and source points; discovering the benefits of gas detection safety monitoring; interpreting how to choose a gas safety monitor; and gaining a free gas safety guide and training checklist.

This educational resource empowers readers to safeguard themselves and their workplace by identifying potential hazards, employing standardized procedures, and installing gas detection safety monitors. All information provided is supported by thorough research and credible statistics, advocating for prioritizing employee safety in any work environment.

As a leading provider of gas detection safety solutions, CO2Meter has served more

than 300,000 locations worldwide since 2006. Its clientele includes national restaurant chains, cold storage facilities, multinational food processors and Fortune 500 companies like Tyson Foods, Kraft Heinz, Chipotle, Walgreens, and Dippin' Dots. These partners rely on CO2Meter's safety solutions for real-time gas monitoring, protecting their staff from overexposure, hypoxia, and fatalities. CO2Meter is committed to offering education, safety resources and superior gas monitoring solutions to ensure workplace safety for its partners presently and in the future. [www.co2meter.com](http://www.co2meter.com)

CO2Meter invites readers to read "The Benefits of Gas Monitoring in Frozen Food Storage, Preservation, and Freezing" by following <https://co2meter.club/food-storage-whp>.



CO2Meter has released a white paper about the fundamentals and best practices for gas monitoring in the growing cryogenic food industry. Credit: CO2Meter

# CAN'T TAKE OUT WHAT WAS NEVER THERE

New advances in manufacturing technology deliver a truly clean ID hose.

**NO MOISTURE | NO OILS | NO GREASES | NO PARTICULATE**

And no need for post-production cleaning, draining, drying or additional testing.

Penflex's CL3 stainless steel hoses mean a streamlined supply chain and more efficient processes.

**HOW WILL YOUR BUSINESS BENEFIT?**



105B Industrial Drive, Gilbertsville PA 19525  
(610) 367-2260 | [www.penflex.com](http://www.penflex.com)

# CryoCoax Revolutionizes Cryogenic Connectivity


by David Phillips, CryoCoax

Intelliconnect has announced the availability of its CryoCoax (a division of Intelliconnect) Q-CON high density cryogenic connectors; these connectors are making waves in the rapidly advancing world of quantum computing. As the quantum computing landscape evolves with the development of large-scale high-qubit machines, there is an increasing demand for microwave cables to facilitate control and readout lines to the quantum processor. Traditionally, these cables were individual coaxial cables fitted with SMA connectors that offered limited packaging flexibility due to their 8 mm hex coupling. They required extra space for tooling during installation.

Quantum processors, designed to operate at temperatures near absolute zero, require specialized equipment to facilitate their functionality. Enter the dilution refrigerator, a crucial component in quantum research labs. These refrigerators are engineered to create and maintain extremely low temperatures, often below 20 mK, at their lowest stage. At these frigid temperatures, quantum processors come to life, enabling groundbreaking research and computation. Within the dilution refrigerator, the challenge lies in ensuring that all components, including microwave cables, connectors and attenuators, operate seamlessly to facilitate the quantum computing process while minimizing passive heat load and thermal noise.

Enter CryoCoax, with its innovative high density multiway connectors based on the SMPM interface. These connectors not only provide a higher density of coaxial lines within a given space but also simplify installation and customization within a dilution refrigerator. Unlike the typical 16 mm spacing between SMA connectors, the new Q-CON high density connectors boast a compact 4.75 mm pitch. The SMPM interface offers a straightforward push-to-mate connection, requiring only a hex key to tighten the two fasteners securely.

The materials used for these connectors are crucial for their performance. CryoCoax ensures top-notch quality by machining the connector components from high-purity and beryllium copper. These components are further enhanced with



**CryoCoax's high-density SMPM connectors simplify quantum processor installations in dilution refrigerators, offering improved spacing and thermal conductivity for demanding low temperature operations in quantum computing.** Credit: CryoCoax


gold plating to optimize thermal conductivity. If non-magnetic versions are needed, CryoCoax can accommodate those specifications as well. These versatile connectors are compatible with 0.047-inch (1.19 mm) size coax, available in various options, including semi-rigid, flexible, or conformable versions. Semi-rigid cables come in a range of materials, including niobium-titanium, stainless steel, copper, cupronickel and beryllium copper, often combined with silver-plated conductors. This variety offers users the flexibility to select the ideal cable for their specific application, balancing thermal conductivity and attenuation.

In cryogenic applications, minimizing passive heat load is a primary concern. Typically, cables with low thermal conductivity are preferred to achieve this goal, although this often results in poor electrical conductivity. For connections between the top of the dilution refrigerator and the control electronics at room temperature, flexible cables with silver-plated copper conductors are commonly used and can be terminated with conventional SMA connectors. Additionally, conformable copper coaxial options are available and are frequently employed in the lowest stage of cryogenic systems.

In quantum applications, superconducting niobium-titanium cables are often specified. However, soldering this material can be challenging, if not impossible. CryoCoax has addressed this challenge by developing solderless connections for high density connectors, as well as traditional SMA, 2.92 and SMP connectors.

The standard configurations of the new Q-CON high density connectors come in 8-way, 16-way and 24-way options, with choices of smooth bore or full detent. These connector blocks can be grouped together, potentially providing hundreds of coax lines within a dilution refrigerator. A mated pair consists of two connector blocks, one featuring a full detent male SMPM interface and the other a smooth bore SMPM male interface. These pairs are complemented by "bullet"-style, female-to-female SMPM adaptors, which are retained in the full detent connector block. Furthermore, CryoCoax offers 8-way, 16-way and 24-way attenuator blocks with options for 0 dB, 3 dB, 6 dB, 10 dB and 20 dB attenuation. Attenuators serve to suppress thermal noise and thermalize the center conductors, enhancing signal quality and reliability.

In collaboration with the National Physical Laboratory, CryoCoax has validated the low temperature reliability of the Q-CON connectors over numerous thermal cycles. Rigorous in-house durability testing has confirmed stable RF performance and DC resistance even after multiple mating cycles. The significance of CryoCoax's innovation has not gone unnoticed. It has been named a finalist in the Interconnection Product of the Year category at the 2023 Electronic Industry Awards. This recognition reflects CryoCoax's dedication to pushing the boundaries of cryogenic connectivity and its commitment to delivering cutting-edge solutions to meet the evolving demands of the quantum computing and cryogenics industries.

CryoCoax is at the forefront of this revolution, providing high density cryogenic connectors that are instrumental in the development and deployment of quantum technologies. These connectors offer a quantum leap in efficiency, installation simplicity and customization flexibility within dilution refrigerators with the promise of more breakthroughs on the horizon, [www.cryo coax.com](http://www.cryo coax.com) 




## NEXUS OF CLEAN™

"Chart's vision is to be the global leader in the design, engineering and manufacturing of cryogenic process technologies and equipment for the Nexus of Clean™ — clean power, clean water, clean food and clean industrials, regardless of molecule."

*Jill* JILL EVANKO / CEO / CHART INDUSTRIES

# CLEAN CLEAN CLEAN CLEAN

 CHART DELIVERS CLEAN SOLUTIONS FOR

 Power  Water  Food  Industrials

 Learn more at [chartindustries.com/esg](https://chartindustries.com/esg)






# HeLIUM Cryogenics Redefines Cryogenic Technology

by Izgin Ozdas, Lead Manufacturing Engineer, Imtek Cryogenics

In an era where technological innovation is not just an advantage but a necessity, HeLIUM Cryogenics™, stands at the vanguard, continually pushing the boundaries of what's possible in cryogenic technology. Presently, a significant milestone is being marked in HeLIUM's journey as it unveils its latest innovation: a new line of mini and mid-range Stirling coolers. These coolers, exemplifying the pinnacle of engineering and design, stand as a testament to HeLIUM's commitment to excellence, offering performance that competes head-to-head with the best in the market while seamlessly integrating efficiency, compactness and environmental sustainability into an advanced product series.

Recognizing the evolving demands of industries, HeLIUM initiated a project to develop an effective and environmentally conscious cooling solution. Its mini-sized coolers are specifically engineered for infrared detectors, marking HeLIUM's initial focus, while its mid-range models are designed for integration into its cryoplants. Shifting from the Gifford-McMahon cycle to the more efficient Stirling cycle for nitrogen liquefaction, this product range reflects HeLIUM's deep commitment to innovation and sustainable practices in cryogenic technology.

At HeLIUM Cryogenics, its R&D initiatives in Stirling coolers involve an interdisciplinary team comprising mechanical, chemical, physics, material science and electronics engineers. HeLIUM Cryogenics' journey since 2015 has been a focused endeavor, steadily advancing and refining the company's cryocooler technology. As a newcomer in the industry, HeLIUM is committed to learning and growing, consistently improving products to meet evolving needs. The first members of HeLIUM's product family are mini rotary Stirling coolers delivering a total cooling power ranging from 250 mW to 1000 mW at 77 K in a 71 °C ambient environment, followed by a 40 W at 77 K mid-range rotary Stirling cooler. Through enhancements in the design and optimization of heat losses within its coolers, HeLIUM has managed to reduce cooldown times and power consumption. This advancement is crucial for applications requiring quick deployment, like emergency response equipment and mobile infrared imaging devices.



**Showcasing HeLIUM Cryogenics' innovation: the 1000 mW @ 71 °C Stirling Cooler alongside its advanced controller, a testament to our precision and expertise in the forefront of cryogenic technology. Credit: Imtek**



HeLIUM Cryogenics' state-of-the-art machining workshops utilize high precision turning and vertical machining centers, achieving sub-micron tolerances of  $\pm 0.1 \mu\text{m}$  and surface roughness as low as  $Ra = 0.010 \mu\text{m}$ . This precision is crucial for manufacturing compressors and cold-finger components with oil-free dry gas bearings, demanding tighter circularity/cylindricity even in 70 HRC materials. Such exacting standards enhance HeLIUM's coolers' cryogenic technology, enabling effective cooling of substantial heat loads. Moreover, this precision-driven approach reduces induced vibration, a critical concern for sensitive equipment. Through design enhancements and the integration of vibration-dampening materials and techniques, HeLIUM has successfully minimized vibration levels in its coolers. HeLIUM Cryogenics handles all design and manufacturing processes internally. The conceptual design phase prioritizes efficiency, user experience and product strategies, setting the groundwork for form, interface features and functionality. Moving into critical design, HeLIUM rigorously assesses the model and its components for thermal and mechanical stresses using finite elements and experimental methods. This step is pivotal in establishing manufacturing tolerances, understanding limits and optimizing design parameters through modeling and simulation studies. This iterative approach

ensures high-quality tests and measurements, facilitating a robust feedback loop for optimization.

HeLIUM Cryogenics stands out with more than 90% of its components precision-crafted in-house, underscoring its dedication to quality. Its advanced component verification lab, equipped with tools like CMM and surface roughness measurement systems, ensures HeLIUM's machining processes are both reliable and efficient. This commitment extends to maximizing thermodynamic efficiency, as it innovates to minimize input power while enhancing cooling performance. The company's coolers consistently deliver under diverse conditions, reflecting our journey beyond mere technological advancement. At HeLIUM Cryogenics, they are not just developing cryogenic technologies; they are shaping the future of the field by blending scientific innovation with practical utility, setting new benchmarks with its Stirling and Joule-Thomson cooler technology, backed by their advanced Cooler Driver Electronic (CDE) system. HeLIUM Cryogenics is driven to enhance industry standards and expand the realm of possibilities in cryogenic technology. [imtekcryogenics.com/en](http://imtekcryogenics.com/en)

*\*HeLIUM Cryogenics™ is a registered trademark of IMTEK Cryogenics. *

## CHANGING THE STANDARD IN QUANTUM INTERCONNECTS



High density multiway connectors based around the SMPM interface which not only allow many more coaxial lines in a given space but also simplify the installation and customisation within a dilution refrigerator.

Offering either soldered or solderless connections for .047" size semi rigid coax NbTi/NbTi, SS/SS, CuNi/CuNi, BeCu/BeCu. As well as flexible and conformable copper coax options.

Standard configurations are 8-way, 16-way or 12-way with either smooth bore or full detent options, these can be combined with 8-way or 12-way attenuator blocks available in 0dB, 3dB, 6dB, 10dB and 20dB.



# Advances in Manufacturing Yield a Clean ID Hose

by Robert P. Barker, President, Penflex

The manufacturing of metal hoses commences with thin material strips that are brought together to form a straight tube. Corrugations are then introduced, enabling flexibility and adaptability across various applications. Different methods are employed to create these corrugations: **Hydroforming** utilizes high-pressure water to push the material from the inside into dies, determining the shape of the corrugations. **Mechanical forming** involves the use of dies split into two sections of a ring, which either squeeze the tube to form a bulge or employ a series of rotating dies around the tube to create corrugations progressively.

While both production methods yield quality hoses for most applications, they possess trade-offs that render them unsuitable for certain uses. In helium-based cryogenic applications, a critical concern arises: "Can a hydroformed hose ever be entirely free of moisture?" Hoses carrying helium demand thorough cleaning to eradicate detrimental contaminants when produced via hydroforming. Contaminants encompass moisture, oils, greases and solvents, as well as any residues from welding or cutting. However the cleaning process itself can lead to recontamination. For instance, while a cleaning agent may remove oil, it might leave solvent, acid, or alkali residues.

Frequently, specifications for metal hose assemblies necessitate post-production cleaning. These specifications detail methods such as cleaning with a spar nozzle or interior mandrel using aqueous solutions, which involve extensive labor followed by draining and oven drying. Additional testing for hydrocarbons or particulate matter is also conducted to ensure cleanliness. However, such post-production processes and tests can be eliminated. Mechanical forming, as employed in Penflex's CL3 process, generates hoses devoid of internal water, oils, solvents and tooling marks. These hoses are clean and devoid of stress risers.

The CL3 mechanical forming process pioneered by Penflex represents a seismic shift in the realm of cryogenics. Its profound impact reverberates across diverse applications within this critical industry. Consider, for instance, the transportation of liquefied gases like helium or hydrogen – where cleanliness and purity are non-negotiable. Some traditional manufacturing methods pose substantial risks to these sensitive substances. However,



**Skills of Penflex's ASME Sec. IX certified welders can be seen on small diameter hose assembly.** Credit: Penflex

the CL3's precision-engineered approach ushers in an era of unparalleled purity within hoses. This innovation isn't merely about eliminating post-production cleaning: it's a fundamental paradigm shift. The absence of moisture exposure during mass spectrometer leak testing ensures the reliability of critical equipment – a game-changer for research, medical, and aerospace applications reliant on accurate cryogenic systems.

Moreover, the CL3 process's streamlined production and reduced need for additional cleaning makes it a catalyst for operational efficiencies across the cryogenic supply chain. As industries push the boundaries of low temperature applications, the CL3 process emerges as a cornerstone of reliability, setting new benchmarks for cleanliness, efficiency and safety in cryogenics. For those in the cryogenics field, a truly clean inside presents opportunities for streamlined supply chains and operational efficiencies. By employing a process that doesn't use water or lubrication on the inside, the need for post-production drying or cleaning – incurred costs that extend delivery times – is eliminated. This allows for faster and more reliable mass spectrometer leak testing, reducing the risk of moisture exposure to testing equipment. In essence, what was never there to begin with doesn't need removal. [www.penflex.com](http://www.penflex.com)

**AEROSPACE Fabrication**  
Engineered for the Extreme.

**Listen. Evaluate. Innovate.**

**Contact us for Down-To-Earth Cryogenic Insulation Solutions**

[www.aerospacefab.com](http://www.aerospacefab.com)

Contact AFM for current availability, pricing, and custom preparation  
mli@aerospacefab.com | 651.463.8500



## PIONEERS IN INFRASTRUCTURE

FLEXWELL® CRYO PIPE

[bruggpipes.com](http://bruggpipes.com)

**BRUGG**  
Pipes

## FLEXIBLE LIQUID NITROGEN PIPING

- Highly Efficient Semiflex®/Triax
- Rugged & Adaptable - fits an array of applications
- Industry Leading Sales & Support

Guaranteed to satisfy your application



**VACUUM BARRIER VBC**

Woburn, MA 01801, USA | 781-933-3570  
[sales@vacuumbarrier.com](mailto:sales@vacuumbarrier.com) | [vacuumbarrier.com](http://vacuumbarrier.com)



## WORLD CLASS MANUFACTURER OF CRYOGENIC VESSELS

Wessington manufactures a range of cryogenic storage vessels, from general purpose open dewars, to multi-coded liquid nitrogen, argon, oxygen and helium vessels. We also pride ourselves on our custom projects and bespoke design services.

### Contact us for more information:

+44 (0)191 512 0677

[sales@wessingtoncryogenics.com](mailto:sales@wessingtoncryogenics.com)

[wessingtoncryogenics.com](http://wessingtoncryogenics.com)

2 Gadwall Road, Rainton Bridge South, Houghton le Spring, Tyne & Wear, DH4 5NL United Kingdom.



# Product Showcase

This Product Showcase is open to all companies and related manufacturers offering new or improved products for cryogenic applications. We invite companies to send us short releases (150 words or fewer) with high-resolution JPEGs of their products to [editor@cryogenicsociety.org](mailto:editor@cryogenicsociety.org).



## Tempshield LLC

### Cryogenic and Vaccine Vial Grippers

The perfect grip for optimal precision, these cryogenic and vaccine vial grippers are designed to safely remove tubes and vials from cold storage boxes with precision. The cryogenic gripper holds microtubes up to 13.5 mm diameter, and the vaccine gripper fits vials with up to 21-mm diameter crimps. The ergonomic squeeze area was designed to prevent hand fatigue. They are cold, chemical and impact resistant, and they are made from reusable, autoclavable, reinforced polypropylene. Available in packages of five assorted colors for easy identification and organization, or in a package of two (one of each type). [www.tempshield.com](http://www.tempshield.com)

## Princeton CryoTech

### CryoCart

CryoCarts are designed for the loading of biological samples into canes, boxes, racks or frames. When used as a portable workbench, the unit will provide a safe and controlled environment for samples for up to eight hours with the lid open. CryoCart is ideal for transporting large quantities of samples from one tank to another within the same facility. In addition to the approximate hold time of eight hours with the lid open, 18 hours is the approximate hold time with the lid on. Omega temperature monitor with type T thermocouple. Traceable calibration certificate with RS232 PC interface. LN<sub>2</sub> transfer hose connection with ball valve and relief valve. [www.princetoncryo.com](http://www.princetoncryo.com)



## Fluoramics, Inc.

### Tufoil Air Tool Oil

Fluoramics introduces new sizes for Tufoil Air Tool Oil, ideal for air compressor tools: 16.5 mL and 118 mL dropper tip bottles. Infused with Fluoramics' Tufoil Technology, this oil ensures optimal lubrication, moisture displacement and rust resistance for compressor-driven tools like hammers, nailers and more, without hazardous solvents. To maintain air tools, disconnect the air line and add a few drops to the air nipple daily, enhancing efficiency and longevity by reducing corrosion and o-ring wear on internal parts. Adding oil to the air coupler is recommended. End-of-day application safeguards interior components from moisture buildup. For continuous daily use, consider using a filter/regulator/lubricator device with the air line. Tufoil Air Tool Oil is available in quart and gallon sizes for industrial lubrication systems. [www.fluoramics.com](http://www.fluoramics.com)



---

## Chart Industries

### LH2 Transport Trailer, ST-18600H 155 Pressure Transfer System

Chart has developed the industry's first 10,000-pound payload ST18600H trailer to improve efficiency and logistics in delivery operations, helping to meet the increasing demand for LH<sub>2</sub>. In times of driver shortages, this trailer with the largest payload in the industry meets US DOT requirements and is California-bridge-law compliant when paired with an appropriate tractor – including alternative fuel tractors utilizing the 82,000-lb GVWR exception. The double-insulated trailers meet the same high performance and operation standards that come with the Chart brand. [www.chartindustries.com](http://www.chartindustries.com)



---

## Aerospace Fabrication & Materials, LLC

### AstraWrap™



Aerospace Fabrication & Materials, LLC (AFM) is rebranding its SpaceWrap™ line as AstraWrap™, focusing on safeguarding spacecraft in orbit and beyond. This rebrand enhances AFM's reputation for innovative passive thermal control solutions employing cutting-edge thin films and engineered fabrics. According to Brent Anderson, Business Development Manager at AFM, their strength lies in combining technical materials with optical and physical properties to mitigate heat flow in space systems. The Astra™ brand aids in conveying component-level data for versatile applications in custom end-use devices for the space industry. The Astra™ brand encompasses multiple product lines, such as AstraWrap™, AstraWrap™ HT, AstraPair™, AstraLam™, AstraLoft™ and AstraTape™, offered in user-friendly forms to create single layer insulation (SLI), multilayer insulation (MLI) blankets and other passive thermal control products. <https://aerospacefab.com/products/spacewrap-ht>

---

## Arrow Finishing Inc.

### Tumble Polishing and Cryogenic Treatment for Extended Wear

Arrow Finishing Inc. offers a comprehensive service combining cryogenic treatment and tumble polishing for various components, promising extensive benefits. This approach enhances wear resistance by fortifying materials against abrasion and refining surfaces to diminish friction, contributing to prolonged component lifespan and reduced maintenance. The synergy between cryogenic treatment and tumble polishing ensures structural reinforcement and improved aesthetics, applicable across diverse materials and industries. Notably, this process delivers superior wear resistance, enhanced surface finish, extended maintenance intervals and increased component longevity and cost savings over the component lifecycle. While these benefits are significant, Arrow Finishing advises tailored consultations to align the treatment strategy with specific component needs, emphasizing the expertise of their materials and surface finishing specialists. [www.arrowfinishing.com](http://www.arrowfinishing.com)



# People & Companies in Cryogenics

Dr. Marcia Rieke, principal investigator for the near-infrared camera on NASA's James Webb Space Telescope is the Astronomical Society of the Pacific's (ASP) 2023 recipient of its most prestigious award. ASP's Catherine Wolfe Bruce Gold Medal honors Rieke, a regents professor of astronomy at the University of Arizona. Rieke's research has focused on infrared observations of the center of the



Marcia Rieke. Credit: George Rieke / UAZ

Milky Way and high redshift galaxies in the early universe. Rieke is considered by many to be one of the "founding mothers of infrared astronomy," and it is for her groundbreaking contributions to astronomical research at these wavelengths that she is being recognized and celebrated. Rieke's award and achievements were recognized at the ASP Awards Gala in November in Redwood City, Calif.

University of Florida's Professor Peter Hirschfeld has been awarded the 2023 Jesse W. Beams Award for his pioneering work in condensed matter physics, particularly in understanding unconventional superconductivity. His research on repulsive Coulomb interactions, multi-orbital bands and innovative theoretical models has advanced our understanding of these



Professor Peter Hirschfeld. Credit: UF

materials. The award, given annually by SESAPS (Southeastern Section of the American Physical Society) since 1973, recognizes physicists in the southeastern United States whose work leads to new discoveries, fundamental insights, or crucial experimental/theoretical techniques in physics.

Stirling Cryogenics B.V. has inaugurated its sales arm, Stirling Cryogenics Inc. (CSA CSM), in the US. Concentrating solely on the US and Canada, the new office in North Carolina appointed Scott Smith as sales manager. This expansion aims to better cater to customer needs, especially in supplying specialized cryogenic sys-



Scott Smith. Credit: Stirling Cryogenics

tems with the distinctive Stirling cryogenerator. Burgeoning projects in energy transition like LNG and liquid hydrogen production in North America, Stirling foresees substantial contributions in these fields. While the company's headquarters and production facilities stay in the Netherlands, the US operations will prioritize sales and service.

The U.S. Department of Energy Office of Science has allocated \$115 million for the High Rigidity Spectrometer (HRS) project at Michigan State University's Facility for Rare Isotope Beams (FRIB, CSA CSM). This innovative instrument, a centerpiece of FRIB's fast-beam program, will analyze rare isotopes created at nearly half the speed of light, characterizing their mass, charge and velocity. This seven-year funding will facilitate HRS's establishment, supporting more than 500 scientists and significantly enhancing FRIB's scientific reach. HRS, operating with near-perfect efficiency, will vastly increase the sensitivity of FRIB's scientific program, extending its capabilities by more than a hundredfold for studying neutron-rich isotopes, enabling experiments impossible elsewhere. Collaborating with a diverse team of institutions globally, FRIB serves a vast



The High Rigidity Spectrometer project at FRIB is highlighted in an artistic rendering showing where it will fit in the FRIB experimental area. Credit: MSU

## Meetings & Events

### American Hydrogen Forum

February 28-29, 2024

Houston, TX

<https://ushydrogenforum.com>

### European Hydrogen Energy Conference

March 6-8, 2024

Bilbao, Spain

<https://ehed.info>

### BCGA Annual Conference 2024

May 16, 2024

Manchester, England

<https://bcga.co.uk/conference2024>

### 23rd International Cryocooler Conference

June 3-6, 2024

Madison, Wisconsin

<https://cryocooler.org>

### Cryogenic Operations 2024

July 17-19, 2024

Grenoble

[www.cryo-ops-2024.fr](http://www.cryo-ops-2024.fr)

### International Cryogenic Engineering Conference/ International Cryogenic Material Conference 2024

July 22-26, 2024

Geneva, Switzerland

<https://icec29-icmc2024.web.cern.ch>

### 2024 Applied Superconductivity Conference

September 1-6, 2024

Salt Lake City, Utah

[www.appliedsuperconductivity.org/asc2024](http://www.appliedsuperconductivity.org/asc2024)

community of researchers, fostering discoveries in nuclear physics, astrophysics and societal applications. The investment reflects DOE-SC's commitment to advancing rare-isotope research capabilities through FRIB, a prominent user facility in the field of Nuclear Physics.

NASA's Deputy Administrator Pam Melroy served as the keynote speaker at the American Geophysical Union annual meeting in San Francisco. Melroy highlighted NASA's Artemis program and its mission to establish a sustained presence on the moon for exploration and scientific research. Throughout the week, researchers shared insights in Earth sciences, planetary science and heliophysics. 🌌

# Taking Cooling to a Completely New Dimension

Get your application out of the lab and into the field with compact, portable mechanical cryocoolers from Sunpower. Our latest offering is a combination of our 30K cryocooler (GTLT) and our advanced active balancer (AVC-GEN2) to create a system specifically beneficial to deployable Quantum research applications.

- Compact, portable cryogenic cooler
- Sub-30K cooling with active vibration cancellation with mass <4.5 kg
- Extremely low exported vibration using **Gen2 AVC** technology
- Highly efficient, low power consumption



CryoTel® GTLT cryocooler with AVC-GEN2 balancer

**SUNPOWER**

**AMETEK**

Learn more at [www.sunpowerinc.com](http://www.sunpowerinc.com)



## Alloy Valves and Control™



### MATERIALS AND SPECIFICATIONS

Body Materials	316SS	316L
End Connections	NPT/SW/BW	Tri-Clamp
	ANSI Flanged	Extended Tube
Valve Service	LN2	LOX
	CO2	LNG

- Since 2000
- Engineered for Engineers
- Interchangeable Components
- Women Business Enterprise
- ISO 9001:2015 Certified
- 3D Models Available
- Full Port or Vee Port
- ASME B16.34

[www.avcovalve.com](http://www.avcovalve.com)

[sales@avcovalve.com](mailto:sales@avcovalve.com)

+1 (714) 427-0877



# Index of Advertisers

Acme Cryogenics	19
Aerospace Fabrication	88
American Magnetics	81
Avco	93
Brugg Pipes	89
Chart Inc.	85
CPC CryoLab	21
Cryo Technologies	Inside Front Cover
Cryoco LLC	7
CryoCoax (Intelliconnect)	87
Cryocomp	7
Cryofab, Inc.	Inside Back Cover
Cryomech, Inc.	24
CryoWorks, Inc.	82
Gardner Cryogenics	17
Lake Shore Cryotronics	23
Linde Engineering NA	Inside Back Cover
Magnatrol Valve	7
Omega Flex, Inc	Back Cover
Penflex Corp	83
PHPK Technologies	Inside Front Cover
Scientific Instruments Inc.	13
Star Cryoelectronics	81
Stirling Cryogenics	18
Sumitomo SHI Cryo America	3
Sunpower	93
Technifab	22
Tempshield Cryo-Protection	22
Vacuum Barrier Corp	89
Vacuum Energy	81
Wessington Cryogenics	89



Join CSA and start receiving Cold Facts!

## Rates: circle \$ amount

In US: Individual \$85 • Student or retiree: \$40  
 Outside US: Individual \$130 • Student or retiree \$80  
 Corporate, in US, number of employees:  
 1-10, \$495 • 11-25, \$695 • 16-50, \$915 • 51-100, \$1,355  
 101-500, \$2,460 • 501-1,000, \$5,515 • 1,000+, \$7,720  
 Corporate, outside of US, number of employees:  
 1-10, \$555 • 11-25, \$765 • 16-50, \$990 • 51-100, \$1,400  
 101-500, \$2,580 • 501-1,000, \$5,725 • 1,000+, \$8,000  
 Government/Non-profit: \$475  
*Outside the US, please remit in US\$ on US bank. No bank transfers.*

## Charge your membership

Discovery    Visa    MasterCard    AmEx

Account number \_\_\_\_\_ Expiration \_\_\_\_\_ Security code \_\_\_\_\_

Signature \_\_\_\_\_

## Please print

Name \_\_\_\_\_ Title \_\_\_\_\_

Company \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State/Country \_\_\_\_\_ Zip + 4 \_\_\_\_\_

Email \_\_\_\_\_ Website \_\_\_\_\_

Phone \_\_\_\_\_ Fax \_\_\_\_\_

## Send to:

New Memberships • Cryogenic Society of America  
 800 Roosevelt Rd. Suite 312-C • Glen Ellyn, IL 60137  
 Fax: 630-790-3095

**Join CSA online!**  
<http://2csa.us/member>

**Cold Facts is the official technical magazine of The Cryogenic Society of America, Inc.** 800 Roosevelt Rd. Suite 312-C • Glen Ellyn, IL 60137  
 Phone: 630-858-7337 Ext. 8765 • Fax: 630-790-3095  
 Email: [membership@cryogenicsociety.org](mailto:membership@cryogenicsociety.org) • Web: [cryogenicsociety.org](http://cryogenicsociety.org)  
 A non-profit technical society serving all those interested in any phase of cryogenics  
 SSN 1085-5262 • December 2023  
 Printed in USA

# We Will Fabricate Your Perfect Cryogenic Solution

Dewars

Containers

Tanks

Cryostats

Transfer Systems

Vacuum  
Components

Vacuum Jacketed  
Valves

VJ Manifolds



Making our world more productive

## Partner you can count on



For over eight decades, we have been enabling ground-breaking discoveries that challenge the boundaries of physics. As the world's leading cryogenic engineering company, we have the technologies, experience and skills to keep cool – while you unravel the secrets of science.

Linde – your trusted partner.

Linde Cryogenics  
A Division of Linde Engineering North America Inc.  
6100 South Yale Avenue, Suite 1200, Tulsa, Oklahoma 74136, USA  
Phone +1 918 477-1200, Fax +1 918 477-1100, [www.leamericas.com](http://www.leamericas.com)

Linde Kryotechnik AG  
Daetlikonerstrasse 5, 8422 Pfungen, Switzerland  
Phone +41 52 304-0555, [www.linde-kryotechnik.ch](http://www.linde-kryotechnik.ch), [info@linde-kryotechnik.ch](mailto:info@linde-kryotechnik.ch)





## Cryogenic / Vacuum Jacketed Hose Assemblies

Keep Cryogenic Liquids Cold • Safety Containment



Cryogenic and Vacuum Jacketed Assemblies are oven dried and purged with argon to a moisture content of 2 PPM and verified with a moisture analyzer.

Assemblies are helium leak checked to  $1 \times 10^{-9}$  std. cc/sec.; and can be charged with helium to maintain dryness during shipping and storage.

OmegaFlex welders and OmegaFlex welding procedures are qualified to Section IX of the ASME Boiler and Pressure Vessel Code. OmegaFlex hose assemblies are tested in accordance with ISO- 10380:2012.

Contact OmegaFlex with your specification and we will engineer a custom jacketed hose assembly for you.

[omegaflex.com](http://omegaflex.com)

© Omega Flex, Inc. 2023



### OmegaFlex Cryogenic / Vacuum Jacketed Hose Assemblies

- Superior insulation properties
- Multi-layer insulation creates a low heat transfer rate
- Minimizes cryogenic liquid boil-off
- Containment of the media in case of inner hose rupture
- Bayonet connections available for quick, leak-resistant installations

### Metal Hose

- Allows for the transfer of liquids or gases, usually at high pressure and high or cryogenic temperature

### Cryogenics Applications

- Nitrogen
- Hydrogen
- Oxygen
- Carbon Dioxide
- Helium
- Argon
- Other Natural Gases



Omega Flex, Inc.  
451 Creamery Way  
Exton, PA 19341  
1-800-671-8622  
ISO 9001 Registered Company  
IND-673 Rev 1223