



Meet the CSA Board ..... 8  
Streamlining Industrial Gas Distribution ..... 12  
Cryo Tech Uncovers Volcanic Secrets ..... 14

CoolCAD Pioneers Cryo Precision ..... 18  
WCS Refines Boundaries ..... 22  
Stirling World Tour ..... 86

# Cold Facts

## 2025 Buyer's Guide | Corporate Directory

The Magazine of the Cryogenic Society of America, Inc.

# INTERNATIONAL

### Products and Services


for Cryogenic and Superconductivity Applications Worldwide





### ENGINEERING MODELING DESIGN

Available models and drawings are:  $L_c = 2.079(2) \times 10^{-10}$  m  
The models used for design & fabrication  
Standard Pressure: 2000psi & at 60K (15000psi)  
 $L_c = 2.079(2) \times 10^{-10}$  m  
 $L_c = 2.079(2) \times 10^{-10}$  m  
From 1000 G to 500000  
From 1000 psi to 50000 psi  
• PHOTON/PHOTON/PHOTON  
• 1000



**Cryo Technologies**  
A Chart Industries Company

### MANUFACTURING



**FRONTI FABRICATIONS**  
A Chart Industries Company

### COMMISSIONING & STARTUP



**CHART**  
Cooler By Design<sup>®</sup>

Specializing in the Design & Fabrication of Hydrogen & Helium Liquefaction Plants

241 N Cedar Crest Blvd, Allentown, PA 18104 610.530.7288 [www.ChartIndustries.com/CryoTech](http://www.ChartIndustries.com/CryoTech)



**PHPK TECHNOLOGIES**

WHEN PERFORMANCE AND RELIABILITY MATTER

- Cold boxes
- High vacuum chambers
- Pressure vessels
- Cryostats
- Helium compressor skids
- Thermal shrouds
- Thermal conditioning units
- Vacuum insulated piping
- Valves
- Couplings

**CVI Torr Master<sup>®</sup>**

- Cryopumps
- Cryocoolers

Proudly Manufactured in the USA

[info@phpk.com](mailto:info@phpk.com)

(614) 486 4750

[www.phpk.com](http://www.phpk.com)



# Elevate Your Cooling Experience

The new RJT-100 GM-JT Cryocooler delivers an impressive 9.0 W at 4.2 K.



RJT-100 Cryocooler  
9.0 W @ 4.2 K

SHI's new RJT-100 expertly combines our highest-capacity Gifford-McMahon 4K Cryocooler with a Joule-Thompson expansion line to create the world's most powerful 4K Cryocooler. We think the advantages speak for themselves:

- Superior efficiency at 4.2K
- Excellent temperature-stabilizing performance
- Reduced maintenance costs
- Inverter-driven compressors

The RJT-100 will elevate your cooling experience in superconducting radio frequency cavities, superconducting magnet applications, low-temperature systems and other applications requiring high cooling capacity at 4.2 K.




# Join Our Growing Family of CSA Corporate Sustaining Members

Get connected to the cryogenic community worldwide. Let your voice be heard and your contributions known.

Abess Instruments and Systems, Inc.	CryoCoax	Imtek Cryogenics	Scientific Instruments, Inc.
Ability Engineering Technology, Inc.	Cryocomp	Independence Cryogenic Engineering, LLC	shirokuma GmbH
Acme Cryogenics, Inc.	CryoEdge	Iris Technology	Sierra Lobo
Ad-Vance Magnetics	Cryofab, Inc.	Isotec Corporation*	SLAC-National Accelerator Laboratory
Aerospace Fabrication & Materials	Cryogenic Institute of New England	Kelvin International Corporation	Space Dynamics Laboratory
Air Liquide Advanced Technologies	Cryogenic Limited	KEYCOM Corporation	Spaceline Technologies Inc.
Alkegen	Cryogenic Specialty Manufacturing SDN BHD	kiutra GmbH	SPS Cryogenics BV
Alloy Valves and Control	Cryoguard LLC	Lake Shore Cryotronics, Inc.	STAR Cryoelectronics
American Magnetics, Inc.	Cryomagnetics, Inc.	Lihan Cryogenics	Stirling Cryogenics BV
Ampo Poyam Valves (AMPO)	Cryomech, Inc.	Linde Cryogenics, Division of Linde Engineering Americas	Sumitomo (SHI) Cryogenics of America, Inc.
Amuneal Manufacturing Corp.	Cryonova Process Systems, LLC	Magnatrol Valve Corporation	Sunpower, Inc.
Argonne National Laboratory	Cryospain	Magnetic Shield Corporation	SuperPower, Inc.
Atlas Technologies	CryoSRV, LLC	Meyer Tool & Mfg., Inc.	Technifab Products, Inc.
Barber-Nichols LLC	CryoTechnics LLC	Micro Harmonics Corporation	Technology Applications, Inc.
Beyond Gravity GMBH	CryoVac GmbH	Midalloy	Tech4 Imaging LLC
Bluefors	CryoWorks, Inc.	Molecular Products, Inc	Tempshield Cryo-Protection
BRUGG Pipes	Cryoworld BV	NASA Kennedy Cryogenics Test Laboratory	The Phoenix Company of Chicago
Canadian Nuclear Laboratories	Danaher Cryogenics	NASA Marshall Space Flight Center	Thermal Management Technologies
CCH Equipment Company	Demaco Holland BV	National High Magnetic Field Laboratory	Thermal Space
Chart Inc.	DMP CryoSystems, Inc.	Niowave, Inc.	Thermionics Lab
Chase Research Cryogenics	EPSIM Corporation	Oak Ridge National Laboratory	Thomas Jefferson National Accelerator Facility
Clark Industries, Inc.	Equigas, Inc.	Omega Flex, Inc.	TRIUMF
Coax Co., LTD.	Eta Space	Oxford Cryosystems	Turbines Inc.
CoolCAD Electronics, LLC	Fabrum Solutions	Oxford Instruments NanoScience	Vacuum Barrier Corporation
Commonwealth Fusion Systems	Facility for Rare Isotope Beams—Michigan State University	Penflex	Vacuum Energy Inc.
CO2 Meter	Fermi National Accelerator Laboratory	Photon Spot	Web Industries
CPC-Cryolab, an MEC Company	Fin Tube Products, Inc.	PHPK Technologies	WEKA AG
Creare LLC	Fives Cryo	Princeton CryoTech	Wessington Cryogenics
Criotec Impianti SpA	Gardner Cryogenics	Quantum Design, Inc.	West Coast Solutions
Cryo Industries of America	Gas Equipment Company	RegO	XMA Corporation
Cryo Service LTDA	Herring Systems, Ltd.	RIX Industries	
Cryo Technologies – A Chart Industries Company	IC Biomedical		
Cryoco LLC			

\* New member since last issue



## 2025 BUYER'S GUIDE

- 25 **Products and Services**
- 42 **Alphabetical Listing**
- 58 **Supplier Profiles**

## FEATURES

- 8 Meet Our New Board Members
- 10 Get to Know Our Returning Directors
- 12 Streamlining Industrial Gas Distribution with Cylinder Outsourcing
- 14 INFICON's Cryo Tech Uncovers Volcanic Secrets on Vulcano and Stromboli
- 15 Book Review—Cryogenic Technologies at the European Spallation Source: A Big Science Case Study

## ON OUR COVER



**Stirling Cryogenics' onsite liquid nitrogen for storage and preserving semen for artificial insemination.** Credit: Stirling Cryogenics

In all instances, "CSA CSM" indicates a Corporate Sustaining Member of CSA.

## COLUMNS

- 6 Executive Director's Letter
- 41 Look who's NEW in the Cold Facts Buyer's Guide
- 79 Zero Resistance Zone: Design Considerations for Cryogenic Supports
- 83 Clean Energy Future: Advanced Thermal Insulation Systems for Low Temperature Applications

## SPOTLIGHTS

- 18 CoolCAD Electronics Pioneers Precision in Cryogenic Testing and Modeling
- 22 WCS Redefines Boundaries in Cryogenics
- 86 Stirling Cryogenics' World Tour

## 90 PRODUCT SHOWCASE

## 92 PEOPLE & COMPANIES

## 92 CALENDAR



OPW/Rego/Acme was CSA's newsletter sponsor for November.



Gardner Cryogenics was CSA's newsletter sponsor for December.

## Cold Facts Magazine

Editor  
ANNE DiPAOLA

Advertising Coordinator  
JAMIE LUEDTKE

Online Marketing Manager  
JO SNYDER

Graphic Designer  
ISRAEL REZA

## CSA Board of Technical Directors

Board Chairman  
JOHN WEISEND II  
European Spallation Source (ERIC)

President  
RICH DAUSMAN  
BLUEFORS

Past President  
AL ZELLER  
NHMFL, FSU

President-Elect  
FRANKLIN MILLER  
UNIVERSITY OF WISCONSIN-MADISON

Executive Director  
MEGAN GALEHER  
Cryogenic Society of America

Managing Director  
RICK CHURCH  
Cryogenic Society of America

## Technical Directors

KATHLEEN AMM, NHMFL FSU

CHARLIE DANAHER, DANAHER CRYOGENICS

ROBERT DUCKWORTH, OAK RIDGE NATIONAL LABORATORY

WEI GUO, FLORIDA STATE UNIVERSITY

JOHN JURNS, NIST CENTER FOR NEUTRON RESEARCH

PETER KNUDSON, UNIVERSITY OF MARYLAND

JACOB LEACHMAN, WASHINGTON STATE UNIVERSITY

SARAH MITCHELL, SUMITOMO (SHI) CRYOGENICS OF AMERICA

SASTRY PAMIDI, FAMU-FSU COLLEGE OF ENGINEERING

STEVEN VAN SCIVER, FLORIDA STATE UNIVERSITY

ADAM SWANGER, NASA KENNEDY SPACE CENTER

Cold Facts (ISSN 1085-5262) is published six times per year by the Cryogenic Society of America, Inc.  
Contents ©2024 Cryogenic Society of America, Inc.

Although CSA makes reasonable efforts to keep the information contained in this magazine accurate, the information is not guaranteed and no responsibility is assumed for errors or omissions. CSA does not warrant the accuracy, completeness, timeliness or merchantability or fitness for a particular purpose of the information contained herein, nor does CSA in any way endorse the individuals and companies described in the magazine or the products and services they may provide.

## From the Executive Director



It's that time of year again! We are proud to present to you our 2025 edition of the printed Buyer's Guide – a resource of products and services designed for cryogenic applications. We hope you find this year's edition to be a useful tool for you to use throughout 2025 and beyond. As a reminder, you can always access the online version of our Buyer's Guide, which is updated regularly at [www.csabg.org](http://www.csabg.org).

With 2024 coming to a close, I enjoy reflecting on the successes CSA has experienced in the last year. The year began with a personal 'success' – I welcomed my third child and was on leave for a few months. The CSA team did a great job covering for me, and I am forever grateful to them for it! Upon my return, we headed to Madison, Wis., to attend ICC23 and to host a CSA Short Course on Foundations of Cryocoolers that took place the day prior to the conference. This course was co-instructed by Dr. Ray Radebaugh and Dr. Fons De Waele. An added bonus: the course was a complete sell out!

In September, we headed to Salt Lake City to attend the Applied Superconductivity Conference (ASC). During ASC, CSA was able to host an exhibit table where we got to meet and visit with many of you. It's always a pleasure to chat with our readers and members to learn about your new

and ongoing projects. Also at ASC, we presented the Roger W. Boom Award to Dr. Ram Dhuley of Fermi National Accelerator Laboratory for his pioneering work on cryocooler conduction-cooled superconducting radio frequency (SRF) cavities, which demonstrated first-ever practical accelerating gradients on an SRF cavity without the use of liquid helium.

Looking forward to 2025, CSA has a lot of exciting things on the horizon. We will be hosting our 31st Space Cryogenics Workshop on May 13-15, 2025, at the Hyatt Regency Lake Tahoe in Incline Village, NV. All aspects of space cryogenics will be represented, with emphasis on those related to space exploration. Workshop participants representing industry, academia and government will share their expertise through oral and poster presentations. For full details and registration, visit [www.spacecryogenicsworkshop.org](http://www.spacecryogenicsworkshop.org).

Directly following the Space Cryogenics Workshop, CSA will host numerous short courses in conjunction with CEC/ICMC in Reno, Nevada, May 18, 2025. More details regarding the short courses can be found on CSA's website at [www.cryogenicsociety.org](http://www.cryogenicsociety.org).

As always, I hope you enjoy this special Buyer's Guide issue of *Cold Facts*. Happy New Year! 🎉

## ColdFacts Editorial Board

Randall Barron,  
ret. Louisiana Tech University  
Jack Bonn, VJ Systems, LLC  
Robert Fagaly, ret. Honeywell  
Peter Kittel, ret. NASA Ames  
Glen McIntosh,  
Cryogenic Analysis and Design LLC

John Pfothenauer, University of Wisconsin-Madison  
Ray Radebaugh, ret. NIST Boulder  
Ralph Scurlock, Kryos Associates,  
ret. University of Southampton  
Niels Tellier, EPSIM Corporation



# Cryogenic Engineering and Safety Annual 5-Day Course

July 14-18, 2025  
Colorado School of Mines  
Golden, Colorado

This 5-day course is designed to provide a solid foundation in cryogenic engineering for both degreed and non-degreed engineers, including operations personnel and technicians using cryogenics.

Register Online at:  
[www.cryocourses.com](http://www.cryocourses.com)

## CRYOCO LLC

David-John Roth  
SME III Cryogenics  
[djroth@cryocourses.com](mailto:djroth@cryocourses.com)  
305-972-8847



On-site courses also available

## Looking for Solenoid Valves to Handle Liquid Oxygen, Argon and Nitrogen?



Magnatrol manufactures high quality, two-way bronze and stainless steel solenoid valves designed to provide rugged, durable service over a wide range of cryogenic applications.

- Type L and M (Bronze) and Type J and K (Stainless Steel) valves to handle liquid oxygen to (-297°), argon (-303°), and nitrogen (-320°)
- Valve pipe sizes from 3/8" up to 3"
- Continuous duty coils for all AC/DC voltages
- Wide range of options including manual override, position indicator, NEMA 4X explosion proof and watertight models, and many more
- All valves fully tested, degreased, and cleaned to keep them free of moisture


For more information, call 973-427-4341, Fax: 973-427-7611, E-mail: [info@magnatrol.com](mailto:info@magnatrol.com) or visit [www.magnatrol.com](http://www.magnatrol.com).



Magnatrol Valve Corporation  
67 Fifth Avenue • Hawthorne, NJ 07507

# design+innovation

- ADR Cryostats • pcSQUID™ Readout Electronics
- LTS and HTS dc SQUIDS • Cryogenic Cable Assemblies
- Mr. SQUID® Demonstration System • Foundry Services
- Superconducting Flex Cables



## STAR CRYOELECTRONICS

Superconductor Technologies for Advanced Research  
505-424-6454 [info@starcryo.com](mailto:info@starcryo.com)  
[www.starcryo.com](http://www.starcryo.com)





# Meet Our New Board Members



As the Cryogenic Society of America moves into an exciting era of innovation and exploration, we're thrilled to introduce the talented professionals who will help guide our organization forward. This year's new board members bring a wealth of expertise from diverse sectors within the field, as well as a shared passion for advancing cryogenic science and technology. Join us as we highlight their unique journeys, perspectives, and vision for the future of cryogenics—a future they're already shaping through their leadership and commitment.

## President-Elect



**Franklin Miller, Ph.D.,**  
Associate Professor,  
University of Wisconsin -  
Madison

Franklin Miller is Associate Professor of Mechanical Engineering at the University of Wisconsin-Madison. Before joining the faculty at the University, Professor Miller worked in the Cryogenics Branch at the NASA Goddard Space Flight Center. While at NASA he worked on developing cooling systems for space flight missions, including systems in operation on the James Webb Space Telescope. Professor Miller has a Ph.D. in Mechanical Engineering with a minor in Physics from the Massachusetts Institute of Technology. His Ph.D. work included modeling the thermodynamic behavior of superfluid 3He-4He mixtures and the development of a novel superfluid Joule-Thomson refrigeration cycle for sub-1 Kelvin cooling. Professor Miller has supervised 23 MS students and 14 Ph.D. students. He has also served on the Board of Directors for the Cryogenic Engineering Conference since 2009, as program chair of the 2013 Cryogenic

Engineering Conference, as co-Chair of the 27th Space Cryogenics Workshop and as the Chair of the 23rd International Cryocooler Conference.

## Directors



**Kathleen Amm, Ph.D.,**  
Director, NHMFL FSU

Kathleen Amm received her B.Sc. in Mathematics and Physics from the University of Toronto and Ph.D. in Condensed Matter Physics from Florida State University. She spent nearly 20 years at GE Global Research, starting as a physicist, climbing through several leadership positions to eventually direct the entire research portfolio for the GE MRI business at the GE Global Research Center. She then served as director of the Magnet Division at Brookhaven National Laboratory (BNL) leading a team of scientists, engineers and technicians developing the future of superconducting magnet technology. In May 2024, she joined the MagLab as director, bringing her more than 25 years of experience in superconductivity and magnet design to the world's largest and highest-powered magnet laboratory. In this role, she oversees the National MagLab's headquarters location at Florida State University, as well as the MagLab facilities at Los Alamos National Laboratory and the University of Florida.



**Charlie Danaher, President,**  
Danaher Cryogenics LTD

Beginning a career in cryogenics in 1998 under Glen McIntosh at Cryogenic Technical Services, Charlie Danaher went on to work at HPD in Boulder, Colorado, from 2002 to 2020. There, they collaborated closely with NIST scientists to design, build, test,


and install a range of cryostats, including wet and dry dilution refrigerators (DRs) and a line of Adiabatic Demagnetization Refrigerator (ADR) cryostats. After years of designing cryostats, their career evolved to include work with scientists around the world, assisting in the planning, specification, and procurement of specialized cryogenic tools. They've had the unique opportunity to develop lasting professional friendships within the field and have contributed articles to Cold Facts Magazine. With gratitude for the support and opportunities offered by the cryogenic community, they are now eager to help guide its future as a board member for the Cryogenic Society of America.



**Wei Guo, Ph.D.,** Professor,  
Florida State University

Dr. Wei Guo is a Professor of Mechanical Engineering at FAMU-FSU College of Engineering and holds an associate position at the National High Magnetic Field Laboratory. His research centers on cryogenics, with applications in quantum fluid dynamics, liquid-helium-based dark matter detection, cryogenic accelerator physics, quantum-fluid-based qubits R&D and liquid hydrogen aviation. After earning his Ph.D. in Physics from Brown University in 2008, he conducted postdoctoral research at Yale University until 2012, then joined Florida State University. Supported by agencies including NSF, DOE, NASA, the Army Research Office, and the Betty Gordon Moore Foundation, Dr. Guo has received many accolades, including the JSPS Invitation Fellowship, the Moore Foundation EPI Award, and the Outstanding Research Accomplishment Award from the FAMU-FSU College of Engineering. In 2023, he was elected an American Physical Society Fellow.






CSA's 2023-2024 Board of Directors. Top row from left to right: Robert Duckworth, Jacob Leachman, Carl Kirkconnell, John Pfothenauer, Jason Hartwig, and John Weisend II. Bottom row from left to right: John Jurns, Michael Meyer, Adam Swanger, Lukas Graber, Sastry Pamidi, Al Zeller, Peter Knudson, and Christopher Rey. Credit: CSA



**Sarah Mitchell**, Marketing Communications Manager, Sumitomo (SHI) Cryogenics of America, Sarah Mitchell has been the Marketing Communications Manager at Sumitomo (SHI) Cryogenics of America, Inc. (SCAI) since 2008, where she plays a pivotal role in driving the company's marketing initiatives supporting their range of cryocoolers,

cryopumps and compressors. She joined SCAI, a longtime CSA corporate sustaining member, in 2006 and holds a bachelor's degree in International Area Studies from Drexel University. With 20 years of progressive marketing experience, Mitchell combines creative and technical expertise to oversee SCAI's marketing operations and provide support and guidance to the SHI Cryogenics Group's global network.

In addition to developing marketing collateral, including occasional content for Cold Facts magazine, she executes several events on behalf of the SHI Cryogenics Group each year. Mitchell is a member of the International Cryocooler Conference (ICC) Board, having served as president from 2020-2022 and chaired ICC22 in June 2022, including coordination of the CSA's Foundations of Cryocoolers course. 

**CRYOWorks** is now part of **CRANE** ChemPharma Energy

VACUUM INSULATED HOSE

VACUUM INSULATED PIPING

SIZES: 1/4" ID - 24" ID

KEEPFULLS


PHASE SEPARATORS

**CRYOWorks provides a wide range of products for the storage, distribution and transfer of cryogenic fluids.**

Manufactured at our facilities in Jurupa Valley, California & Montgomery, Texas

**CONTACT US TODAY**

shop.cryoworks.net | www.cryoworks.net | sales@cryoworks.net



**Cryogenic Valves & Vacuum Components**

**Large Inventory for Immediate Shipment**

- ▼ Vacuum Jacketed Valves
- ▼ Vacuum Seal-Off Valves & Valve Operators
- ▼ Vacuum Relief Valves
- ▼ Coldbox Valves
- ▼ Vapor Vents & Heaters
- ▼ Pipe & Tube Sized Bayonets

**For Reliable, Long-Life Cryogenic Components Contact [sales@cryocomp.com](mailto:sales@cryocomp.com)**

**CRYOCOMP** +1 908.686.3643

a division of Cryofab, Inc. cryocomp.com



# Returning Directors



## Chairman



**J.G. Weisend**, Senior Accelerator Engineer, European Spallation Source

John Weisend is a Senior Accelerator Engineer at the European Spallation Source and Adjunct Professor at Lund University in Sweden. Dr. Weisend's interests include He II, cryogenic safety, large scale accelerator cryogenics and the development of large international science projects. His publications include: Superfluid, He is for Helium, Going for Cold (co-authored with T. Meaden), Cryogenic Safety (co-authored with T. Peterson), Cryogenic Two-Phase Flow (co-authored with N. Filina) and editor of the Handbook of Cryogenic Engineering and of Cryostat Design. He writes a regular column "Cryo Bios" for the publication Cold Facts. He is Editor in Chief for the journal Interactions. He is the chair of the Cryogenic Society of America and the International Cryogenic Engineering Conference Board.

## President



**Rich Dausman**, President, Bluefors Syracuse

Richard Dausman is currently the president at Bluefors Syracuse. Dausman holds a B.S. in mechanical engineering from Syracuse University. He joined Cryomech in 1976 and has held numerous positions with the company under the tutelage of William "Bill" Gifford and his son Peter. Mr. Dausman continues to be a key contributor in fostering the steady growth and development of Cryomech into a leading

manufacturer of cryogenic systems. Before his current position, Mr. Dausman was vice president of engineering. His activities focused on the design, development and manufacturing of the company's broad product line. He has extensive experience in a wide range of cryogenic techniques, applications and systems integration. He chaired the 18th International Cryocooler Conference hosted in Syracuse, N.Y and is a past member of the Cryogenic Engineering Conference Board of Directors.

## Past President



**Al Zeller** holds a Ph.D. from Florida State University (1974) and has over 40 years of experience in cryogenics. His career includes roles as a Research Associate at FSU, Australian National University, and Texas A&M (1974-1978), Senior Physicist at NSCL/MSU, and Associate Project Manager for FRIB/MSU, retiring in 2017. He has served as ASC Chair (2006), ASC Co-chair (2016), and CEC Chair (1999 and 2011). On the CSA Board, he has held positions as Treasurer, President, Past-President, and served as Editor-in-Chief for ASC 2018, 2020, and 2022. He is also a CEC Technical Editor, with over 120 publications in refereed journals and numerous DOE and NSF grants.

## Directors



**Robert Duckworth**, Ph.D., Senior R&D Staff / Fusion Technology Group Leader, Oak Ridge National Laboratory

Robert Duckworth has been working in the fields of cryogenics and superconductivity for the past 20 years. This work started in the cryogenics group at the University of Wisconsin-Madison where he worked under Dr. John Pfothenauer on a variety of cryogenic and superconducting materials projects. He joined the Applied Superconductivity Group at Oak Ridge National Laboratory in 2001 to work primarily on high temperature superconducting applications such as power cables, transformers and motors for the electric grid. As this program ended, Robert transitioned into the Plasma Technology and Applications Group in the Fusion Energy Division to work on cryogenic and vacuum R&D supporting plasma fueling and disruption mitigation for the fusion demonstrations with an emphasis on supporting ITER. He currently leads the Fusion Technology group at Oak Ridge National Laboratory and is responsible for the superconducting magnet system construction and installation for the Material Plasma Exposure eXperiment.



**John Jurns**, M.S.M.E., Senior Cryogenic Engineer, National Institute of Standards and Technology

John Jurns is a senior engineer with a B.S. from SUNY at Buffalo and a M.S. from Cleveland State University. His technical background focuses on cryogenic system and component design, development, research, testing and operations. He began his career at what is now Praxair, designing bulk cryogenic storage systems. He then moved on to research and technology, working at the NASA Glenn Research Center. At NASA, he was responsible for cryogenic program development, design, build-up and operation



of cryogenic test facilities. Following NASA, he worked at the European Spallation Source in Sweden as lead engineer responsible for the specification, procurement, and installation of a helium refrigeration system. John currently works at the NIST Center for Neutron Research, leading a team responsible for design and operation of the cryogenic infrastructure supporting NIST's research reactor.



**Pete Knudsen, Ph.D.,**  
Engineering and Physical  
Sciences Researcher, US  
Department of Defense,  
CSA Fellow

Dr. Pete Knudsen began his career over 30 years ago for NASA at the Kennedy Space Center (KSC) as a systems engineer for the Space Shuttle. He then worked in KSC's Design Engineering Directorate on orbiter vehicle ground support systems requiring high pressure gas, cryogenic fluids and propellants. His last position was as a senior staff engineer in the cryogenics group at the Thomas Jefferson National Accelerator Facility (JLab), where he was responsible for the process and mechanical engineering design of many helium cryogenic systems, including those at other DOE labs and for NASA. Presently he works as senior cryogenic process engineer at the Facility for Rare Isotope Beams (FRIB) at Michigan State University, and co-leads a collaboration between the College of Engineering and FRIB. His responsibilities include the process design and planning of helium cryogenic systems, cryogenic system R&D, and the oversight and teaching of students in cryogenic engineering.



**Jacob Leachman, Ph.D.,**  
Associate Professor,  
School of Mechanical and  
Materials Engineering,  
Washington State University

Jacob Leachman is an Associate Professor in the School of Mechanical and Materials Engineering at Washington State University (WSU). He initiated the Hydrogen Properties for Energy Research (HYPER) Laboratory at WSU in 2010. He earned a B.S. degree in Mechanical Engineering in 2005 and a M.S. degree in 2007 from the University of Idaho. His master's thesis has

been adopted as the foundation for hydrogen fueling standards and custody exchange, in addition to winning the Western Association of Graduate Schools' Distinguished Thesis Award for 2008. He completed his Ph.D. in the Cryogenic Engineering Laboratory at the University of Wisconsin-Madison in 2010 under the advisement of John Pfothenauer and Greg Nellis. He is the lead author of the reference text "Thermodynamic Properties of Cryogenic Fluids: 2nd Edition." In 2018, he received the Roger W. Boom Award from the Cryogenic Society of America.



**Sastry Pamidi, Ph.D., MBA,**  
Professor and Associate  
Director, FAMU-FSU  
College of Engineering and  
The Center for Advanced

Power Systems

Dr. Pamidi is a professor and the chair of the Electrical and Computer Engineering Department at FAMU-FSU College of Engineering. He is the Associate Director of the Florida State University Center for Advanced Power Systems (CAPS), where he leads a multidisciplinary research group in large cryogenic systems, superconducting devices, cryogenic dielectrics, and advanced cryogenic measurement systems. His current research interests include cryogenic and superconducting technology for electric aircraft and ships. Prof. Pamidi's group has established advanced experimental facilities and expertise for the characterization of superconducting devices under pressurized cryogenic helium gas and liquid nitrogen circulation. Many researchers and small businesses use his facilities collaboratively. In his 35+ years in cryogenics and superconductivity, Professor Pamidi published 200+ papers. He is professionally active in the superconductivity and cryogenics communities. He served on the organizing, program, and editorial committees of several conferences in the cryogenics area. He was the chair of the International Cryocoolers Conference 2020. He is on the boards of the ICC and CEC Conferences. Dr. Pamidi is a Fellow of the Cryogenic Society of America.



**Adam M. Swanger,**  
Principal Investigator,  
Cryogenics, NASA Kennedy  
Space Center / Cryogenics  
Test Laboratory

Adam M. Swanger is the Principal Investigator for the Cryogenics Test Laboratory at NASA Kennedy Space Center. Mr. Swanger holds a MS in Mechanical Engineering from the University of Central Florida, and a BS in Aerospace Engineering from The Ohio State University. He has been working in the field of cryogenics and liquid hydrogen for over ten years, with a focus on providing practical solutions to low temperature problems in both active and passive thermal systems. He has led projects for NASA, the US Department of Energy and National Institute for Occupational Safety and Health, and collaborated with many commercial and academic partners from around the world. He is a lifetime member of the Cryogenic Society of America, and regularly contributes to international conferences such as the Cryogenic Engineering Conference and Space Cryogenics Workshop, and publications such as *Cold Facts* and *Gasworld* magazines.



**Steven Van Sciver, Ph.D.,**  
Emeritus Professor,  
Florida State University,  
Mechanical Engineering  
Department

Dr. Van Sciver is an Emeritus Professor at Florida State University. Before retirement, he was a Distinguished Research Professor and John H. Gorrie Professor of Mechanical Engineering. He was also a Program Director at the National High Magnetic Field Laboratory (NHMFL). Dr. Van Sciver joined the FAMU-FSU College of Engineering and the NHMFL in 1991, initiating and teaching a graduate program in magnet and materials engineering and in cryogenic thermal sciences and heat transfer. He also led the NHMFL development efforts of the cryogenic systems for the NHMFL Hybrid and 900 MHz NMR superconducting magnets. Between 1997 and 2003, he served as Director of Magnet Science and Technology at the NHMFL. Dr. Van Sciver is a Fellow of the ASME and CSA and former American Editor for the journal *Cryogenics*. He is the 2010 recipient of the Kurt Mendelssohn Award and the 2017 recipient of the Samuel Collins Award. 🇺🇸

# Streamlining Industrial Gas Distribution with Cylinder Outsourcing

by Chris Manning

By streamlining the acquisition, recertification and repair of gas cylinders, industrial gas distributors can increase profitability. Industrial gas distributors, responsible for filling and supplying compressed gas cylinders for sale or rental, are crucial to diverse sectors. They deliver essential gases like nitrogen, oxygen, argon, carbon dioxide, hydrogen, helium, methane and propane to a variety of industries, including electronics, government, medical, welding, food and beverage, fire protection and aviation.

Nevertheless, they are in business to turn a profit and must leverage the most economically efficient methods to maximize revenue and minimize operational costs. This is equally important when acquiring new or refurbished gas cylinders or recertifying or repairing existing ones. "By outsourcing to a third-party cylinder supplier, small to mid-sized independent gas distributors can save time and reduce costs, allowing them to focus on serving their customers," says Ed Burcham, area manager of Ozarc Gas and Equipment.

Over the past 30 years, Burcham has acquired new and refurbished cylinders and has sent cylinders out for recertification to established third parties. He states that even the largest distributors outsource due to the complexities involved in specifying, refurbishing and testing cylinders. Ozarc Gas and Equipment supplies industrial gases and welding equipment in Missouri and, along with other locations, is part of a larger network of distributors owned by Meritus Gas Partners.

According to Burcham, when choosing a reputable supplier, it is important to look for key traits: a supplier should be able to source cylinders worldwide, which lowers the distributor's shipping costs. They should provide cylinders that not only function properly but also adhere to precise specifications. Finally, whether dealing with cryogenic or non-cryogenic cylinders, a supplier should manage these processes themselves, reducing costs and time for the distributor.



**To maximize revenue and reduce costs, industrial gas distributors should consider outsourcing cylinder acquisition and recertification to third-party suppliers.** Credit: Quest Cylinders

Ultimately, a distributor should clearly discern the value and benefits of any chosen cylinder supplier before entering a partnership with them.

## New Gas Cylinders

The business model for industrial gas distributors typically involves acquiring cylinders and renting them to customers. Consequently, they need a substantial inventory of cylinders in various sizes. As the business expands, these demands increase correspondingly.

Today, new cylinders are available from only a handful of U.S.-based manufacturers. However, U.S.-based third parties can source cylinders from reputable overseas sources that conform to U.S. specifications (including those related to coatings, markings and legal requirements).

According to Burcham, Quest Cylinder effectively navigates this challenge by sourcing the primed shell offshore. The company specializes in new and refurbished compressed gas cylinders as well as performing cryogenic repairs, service and sales. The

shell arrives with all the legal markings and a valve, if specified. Quest Cylinder then takes the shell and performs all necessary steps to prepare the cylinder for the distributor, including adding the valve if needed, which must meet stringent safety standards and be tailored to the specific gas type to prevent leaks, overpressure, or cross-contamination between gases.

## Refurbished Gas Cylinders

Distributors might also consider purchasing refurbished cylinders. While large distributors are gradually moving toward refurbished cylinders as a cost-saving measure, it is typically the small- to mid-sized distributors who recognize refurbished cylinders as a perfectly viable alternative to new ones. Of course, refurbished cylinders must meet the same specifications as new cylinders.

For small to mid-sized independent gas distributors, the decision to acquire refurbished cylinders is driven by "cost and the bottom line," says Burcham, adding that there are also times when new cylinders are in short supply.



Quest Cylinder's refurbished cylinders, which can be cryogenic or non-cryogenic, are shot-blasted, hydrostatically tested, painted/embossed/stenciled, stamped per DOT specifications when required and outfitted with new valves. They can bring a distributor's entire fleet of cylinders up to code by refurbishing them, or the distributor can purchase the cylinders "as is" and take the required steps themselves to meet compliance.

## Recertifying Cylinders

Distributors can realize value in more areas than just cylinder acquisition. Generally, non-cryogenic cylinders must be recertified every 5 to 10 years, depending on the cylinder type, the material it is made of and the regulatory standards it falls under. Some cylinders, particularly those used for high-pressure gases or under DOT regulation (like DOT-4L cylinders for liquid gases), must be recertified every 5 years. For certain cylinders, particularly low-pressure or specific stainless-steel models, recertification can extend to 10 years.

Regardless of how often recertification is required, Burcham says the investment in the equipment required for in-house testing is cost-prohibitive for most independent distributors. "Outsourcing testing and recertification is beneficial because it reduces any potential liability," says Burcham, adding that a company like Quest Cylinder takes full responsibility for testing and recertification, as well as maintaining all the required documentation. He also appreciates the speed of turnaround, "which is important to me because if the cylinders sit at their location, they are not at the customer's site generating rental income."

## Repairing Cryogenic Cylinders

To achieve cryogenic temperatures, many companies, such as those in the health care, aerospace and energy industries, require gas in cryogenic cylinders and often purchase cryogenic tanks and equipment for long-term use. This is common in high-volume operations that require continuous access to large amounts of gases. Smaller companies or those with intermittent needs



**Outsourcing cylinder acquisition allows small to mid-sized distributors to focus on customer service while benefiting from cost and time savings.** Credit: Quest Cylinders

for cryogenic gases (e.g., research institutions, small manufacturers) often only rent cylinders.

Regardless, like all cylinders, cryogenic cylinders are prone to wear and tear and must eventually be repaired to ensure their safety and structural integrity. Repair procedures vary, but they are often long and involved. A technician typically performs a visual inspection of the outer tank and components, removes the float gauge assembly for inspection, breaks the vacuum or backfills with GN<sub>2</sub>, replaces the POV, checks for leaks using a helium mass spectrometer, bakes the vessel at a range of 250-350 degrees F to reactivate the molecular sieve, reevaluates the annular space to 10 microns or less, repairs/replaces any defective plumbing, performs a bench-set pressure build, economizes the regulators and pop-tests the relief valves.

Finally, they perform gas pressure and liquid tests to check for leaks, ensuring the tank, regulator and valves meet industrial gas and manufacturer standards. To save time and money, it is worth outsourcing this process to an outside supplier who can quickly and efficiently perform this work in their facility and then ship the repaired cylinder back to the distributor.

Like any other business, a distributor must focus on reducing costs and improving time efficiency. Since gas cylinders must be

replaced, refurbished, recertified and repaired, the most economical way to achieve this is to outsource this work to a credible third party, freeing the distributor to concentrate on their own business as well as their customers' needs. [www.questcylinder.com](http://www.questcylinder.com)

## NEWSFLASHES

Stay up to date  
on CSA news.

Learn more/subscribe.

<https://2csa.org/nf>

# INFICON's Cryo Tech Uncovers Volcanic Secrets on Vulcano and Stromboli

by Séverine Grimberg, INFICON GmbH

Volcanism is one of Earth's most powerful forces, reshaping landscapes and impacting ecosystems in dramatic ways. To advance the prediction of volcanic eruptions, INFICON GmbH, a leader in measurement and sensor technologies, is partnering with scientists and research institutions to monitor volcanic activity on Italy's Vulcano and Stromboli islands. This collaboration uses INFICON's advanced instruments to perform geochemical measurements of gases emitted from the ground, offering insights that could help forecast eruptions with greater accuracy.

Vulcano, one of the seven inhabited Aeolian Islands in the Tyrrhenian Sea, has been a focal point for volcanic research since June 2022. The island's volcanic activity, marked by sulfur emissions and a rich history, has made it an ideal research site. According to Professor Andres Diaz and Josef Grenz, the data collected here holds significance beyond volcano studies, contributing to environmental safety for future generations.

This research project includes a team from INFICON's Syracuse and Cologne sites working alongside the Italian National Institute of Geophysics and Volcanology (INGV), NASA, ESA, and ASI. Together, these experts aim to improve monitoring methods and enhance civil protection protocols for people living near active volcanic craters.

One critical focus of this study is understanding the behavior of liquid magma. Italian researchers from INGV's Geological Institute in Palermo explain that geochemical monitoring allows them to quantify outgassing magma, indirectly indicating the amount of magma present. This information helps categorize eruption risks, as magma often seeks a path toward the Earth's surface under increasing pressure.

INFICON's specialized instruments, which detect gases at the crater and nearby, are essential to this project. "When working



*To improve the prediction of volcanic eruptions, INFICON, a specialist in measurement and sensor technologies, is working with scientists and international research institutions on the Italian islands of Vulcano and Stromboli. Credit: INFICON*


directly at volcanic craters, we need robust, reliable equipment that can withstand extreme volcanic conditions," says Emre Germen, INFICON's market manager. Their tools, including portable gas analyzers and leak detection technology, monitor gases such as CO<sub>2</sub>, H<sub>2</sub>S, SO<sub>2</sub>, and helium. The data collected reveal patterns in gas composition and flow that signal changes in volcanic activity.

In this challenging environment, INFICON's mobile devices have transformed from large lab equipment into compact, user-friendly units powered by solar modules and batteries. The advanced sensors enable in-situ and real-time monitoring, wirelessly transmitting data to provide a comprehensive picture of volcanic outgassing processes. This continuous monitoring complements other techniques like seismometry, magnetic measurements, and remote sensing.

For example, INFICON's helium sensor, "He-Man," detects trace amounts of helium via a helium-permeable membrane using Penning ionization. These readings

help refine existing instruments and contribute valuable data for future development.

INFICON also provides advanced instrumentation and sensor technologies that optimize productivity and quality across diverse sectors, including semiconductor manufacturing, air conditioning, and automotive advancements. With a global presence and headquarters in Switzerland, INFICON supports critical processes in industrial applications, life sciences and environmental monitoring.

The Vulcano project not only strengthens local safety protocols but also benefits global volcano monitoring efforts. The data from these field campaigns calibrate remote sensing tools such as NASA-JPL's HyTES (Hyperspectral Thermal Emission Spectrometer) and support the development of future satellites, including HypSIIRI. The information gathered here will contribute significantly to the global monitoring of volcanic activities, allowing civil protection agencies to prepare better emergency responses. [www.inficon.com](http://www.inficon.com) 



# Book Review—*Cryogenic Technologies at the European Spallation Source: A Big Science Case Study*

Reviewed by Tom Peterson, [tjpete@slac.stanford.edu](mailto:tjpete@slac.stanford.edu)

The European Spallation Source (ESS), nearing completion, will be a state-of-the-art research facility for probing materials with neutrons. Neutrons, in a manner complementary to X-rays from light sources, serve as a valuable tool for studying properties of matter at the atomic level. Various cryogenic systems support ESS, including 2 Kelvin helium cooling of the proton linac, the liquid hydrogen moderator for cooling the neutrons produced by proton-target collisions, and various test facilities.

Quoting from the preface of *Cryogenic Technologies at the European Spallation Source: A Big Science Case Study*, the goals of this book are to:

- Describe in detail the final installed cryogenic system at ESS and its performance to date.
- Describe the processes by which the system was designed, procured, and installed, including collaborations with in-kind partners.
- Provide lessons learned that are useful for future projects.
- Ensure that proper credit is given to everyone who contributed to the ESS cryogenics system.

In 12 chapters spanning over 430 pages, the authors skillfully and thoroughly accomplish these goals.

ESS has been a 14-year effort since the project's start in 2009. The large, complex cryogenic support systems represent more than 50 million euros of value. ESS is not only a large science project but a new laboratory built on a "green field" site. Thus, the design, procurement, and construction of the ESS cryogenics system included not only new physical infrastructure but also a fully new organization, large procurements, and in-kind contributions from other laboratories. Documenting this endeavor to build not only a large science facility but also a


new laboratory provided a prime motivation for this book.

True to its name, ESS is a European effort. Sweden and Denmark serve as the host states for ESS, with the laboratory in Lund, Sweden, and with Denmark hosting the data management and science center in Copenhagen. Sweden and Denmark provide about half of the costs, with the balance coming from 11 non-host European states. The book lists the names of more than 250 people who contributed to the development of ESS, 17 of whom served as co-authors of various chapters and for whom biographies are provided.

The authors essentially provide a series of detailed design reports about all things

cryogenic at ESS. The editor, John Weisend (CSA Chairman), authored the introduction and a closing chapter on "Lessons Learned and Final Comments" as well as co-authoring Chapter 2, "An Overview of the ESS Cryogenic System and Its Design Evolution." Chapters 3 through 11 each describe a system in detail: the accelerator cryogenic plant, cryogenic distribution system, target modulator cryogenic plant, cryogenic moderator system, the test and instruments cryoplant and auxiliary systems, elliptical cavity cryomodules including ESS superconducting radio frequency collaboration, spoke cavity cryomodules, cryogenic testing of elliptical cryomodules at ESS, and cryomodule testing in the FREIA laboratory at Uppsala University. These cryogenic systems and

► *continues on page 16*



low-temperature devices presented an impressive variety of technical challenges. Chapters are written by different experts or teams of experts who were among the leaders of their portions of the project, with some people contributing to more than one chapter.

A valuable feature of the book is an organizational pattern common to each chapter. Authors provide motivation and goals, detailed accounts of requirements, design, procurement including source selection processes, testing, and a summary of lessons learned for their project.

The depth of information is most impressive. Chapter 6, for example, on the cryogenic moderator system with a focus on the liquid hydrogen neutron cooling system, spans 74 pages, includes 42 references, and could serve as a text on fluid-flow and pressure design for cryogenic systems. Management and organizational issues are also presented, and this chapter, like the

others, concludes with specific lessons learned. The other chapters cover their respective topics with a similar level of rigor, depth, and clarity.

Lessons learned cited by the authors include:

- Bring skilled people, including technicians, on board early.
- Good communication and transfer of knowledge via open and free communication among ESS and partner lab staff was crucial.
- Early engagement with suppliers is also valuable; get their input.
- Provide as much time and budget as possible for prototype development and testing.

None of these lessons comes as a surprise to people involved in this kind of large-scale science project, but these messages deserve repeating. Too often, such activities are victims of budgetary or schedule

constraints, and the long-term costs and schedule delays from such cuts may exceed the short-term gains. This book documents the impact and importance of these activities for ESS.

The scope of information provided will make *Cryogenic Technologies at the European Spallation Source* a valuable reference for scientific project managers while also providing a wealth of technical information about ESS cryogenics and large-scale cryogenic systems. 📖



Hardback: \$190.00 USD

Ebook: \$159.99 USD

<https://2csa.org/mn6>

DESIGN • DEVELOP • MANUFACTURE • SUPPORT

Atlas  
TECHNOLOGIES

**ENGINEER GREAT THINGS**  
with bonded dissimilar  
metal solutions

- Maximize thermal performance
- Reduce costs and complexity

 [AtlasUHV.com](https://atlasuhv.com)





# Moving you ahead.

Gardner Cryogenics is a world leader in the storage and transport of liquid hydrogen and helium. We help you move and store molecules with near-zero loss.

## **UNIQUE TECHNOLOGIES**

Gardner's leading-edge technologies provide the lowest heat-leak for the longest hold times and highest yields. Our liquid helium and liquid hydrogen distribution systems are the most reliable, safest, and most efficient in operation.

## **WORLD-CLASS MANUFACTURING**

Gardner manufactures the world's safest, most reliable containers and vacuum lines. We are ISO 9001 certified and have extensive experience with extreme cryogenics.


## **PROVEN PERFORMANCE**

Gardner has produced over 1800 tanks and containers, and our first container is still in operation. We operate the most liquid hydrogen transport equipment in the world.

## **RESPONSIVE SERVICE**

Gardner specializes in world-class container rehab, transport damage repair, modifications and upgrades, and vacuum reconditioning. We adhere to worldwide code standards.

At Gardner, we reach beyond mechanical production into the realm of technical artistry, elevating our technology into a class by itself.



**GARDNER  
CRYOGENICS**

gardnercryo.com • 610-266-3700  
gardnsa@gardnercryo.com


# CoolCAD Electronics Pioneers Precision in Cryogenic Testing and Modeling

by Doug Dixon, CoolCAD Electronics


CoolCAD Electronics is a leading provider of electrical test services (current-voltage, capacitance-voltage, noise, transients, etc.) and compact modeling (SPICE) for companies and agencies fabricating and/or designing electronics for low temperature operation. CoolCAD Electronics is a leading-edge company specializing in cryogenic electronics design, testing, and characterization of semiconductor devices operating at ultralow temperatures. With the growing importance of cryogenic technologies in fields like quantum computing, superconducting circuits, and high-performance computing, CoolCAD addresses the unique challenges posed by extreme environments. The company's work enables precise device characterization at temperatures as low as 4 K, offering insights into semiconductor behavior and performance in cryogenic conditions. As demand for robust, high-performance cryogenic electronics increases, CoolCAD provides the tools and expertise required to ensure reliability and functionality in these challenging environments.

Cryogenic testing presents challenges that conventional room-temperature testing methods cannot address. Near absolute zero, semiconductor materials undergo significant changes in electrical properties, including variations in carrier mobility, material structure, and electron trapping behaviors. These effects can lead to performance degradation that traditional testing systems cannot detect. CoolCAD has developed state-of-the-art testing platforms to capture these temperature-induced phenomena with unprecedented accuracy. Their advanced equipment, such as ultra-fast I-V (current-voltage) measurement systems, allows engineers and researchers to observe device behavior at cryogenic temperatures in real time, with a time resolution down to 20 nanoseconds. This ability to conduct fast timescale measurements is crucial for uncovering complex transient dynamics in cryogenic devices.

► continues on page 20



Top view of the cryogenic probe station showing all the probes and high-speed cables in the chamber with devices under test and the cold sample stage that is temperature controlled down to ~4 K. Low temperature capacitance voltage measurements are used to characterize various CMOS technology nodes. Credit: CoolCAD



Gate voltage dependent drain current versus drain voltage curves of a narrow device ( $W/L = 10/0.27$ , both dimensions are in micrometers) measured at 4K. These measurements along with measurements of other size devices are used to extract a SPICE modelcard. The simulated curves (black lines with + symbol) are compared with an example set of measurements (colored lines). Credit: CoolCAD





**DURABLE**

Ball cage interface with receptacle adapter ring guides and locks the nozzle in place for optimum engagement and user interface to increase environmental seal life.

**REGO**  **CRYOMAC®4**  
 LNG FUELING NOZZLE

- Safe, with added safety to operator
- High Durability, increases seal life
- Certified with ISO12617:2017

Patented nozzle safety feature is recognized in the market as a major failsafe advantage for the operator.

Continuing innovations coming soon, Cryomac®5!



Scan the QR code to learn more about the Cryomac®4

**CPC-Cryolab**  **MODEL CV8BS**  
 BELLOW SEAL

- Lightweight valve
- Bellows seal technology ensures zero leakage
- Valves size up to 12"
- Tailored to meet your specifications

Bellows rigorously qualified by leading industry companies for critical applications.



Scan the QR code to learn more and contact us

**MANUAL OR ACTUATED**

The CV8BS offers a Standard quick open, EQ%, Linear Hyperbolic Purge Riser Over Seat and/or Under Seat.

Specially designed for higher rated working pressures, and a special extended length for helium service.

**BELLOWS OR NON-BELLOWS**

Globe, "Y" pattern, and Right Angle pattern designs.



**Electric Trim Heaters**



**Electric Vaporizers**



**Shell and Tube**



**Water Bath Vaporizers**




**VAPORIZERS**

- Full line for both process and disposal
- Several styles for custom-designed systems
- Design & specify 1kW gas heaters to large capacity custom-designed systems



Scan the QR code to learn more about ACME Cryogenic Experts (CEXi) vaporizers.



The CMOS device measurements obtained in a low temperature probe station show that the drive current of a CMOS device usually increases with temperature decreasing. In addition to current-voltage and capacitance-voltage measurements, we regularly perform 1/f and random telegraph noise experiments. A typical 1/f time domain signal and its frequency domain counterpart are shown on the right. Credit: CoolCAD

One of CoolCAD's key innovations is its ultrafast I-V measurement system, which enables detailed analysis of charge trapping and de-trapping dynamics in low temperature semiconductor devices. Charge traps—often caused by defects or impurities—can impact cryogenic circuit performance, especially in applications where precision and reliability are paramount, such as quantum computing. By tracking shifts in device parameters like threshold voltage and transconductance ( $g_m$ ), CoolCAD's testing platform provides insights into both fast and slow charge traps that degrade performance. These measurements are essential for understanding cryogenic device operation and play a critical role in high-performance cryogenic electronics development.

The ultrafast I-V measurement system developed by CoolCAD and NIST researchers also allows analysis of transient effects over a broad range of pulse durations, from nanoseconds to milliseconds. This flexibility enables researchers to capture both fast, short-lived phenomena and slower, thermally driven trapping events. The ability to observe both behaviors is essential for understanding device operation in low-temperature environments. For example, some charge traps may be linked to interface states that become apparent only at cryogenic temperatures. By capturing these effects, CoolCAD's technology identifies potential performance bottlenecks, allowing engineers to optimize device performance before deployment in real-world applications.



Two of our low and high temperature probing setups are shown here. Using these setups, we perform chip measurements from 4 K to 1000 K, with current and voltage ranges spanning from a fraction of a picoamp to an amp, and a microvolt to hundreds of volts, respectively. These also allow for the measurement of a fraction of a picofarad. Credit: CoolCAD

In addition to its testing capabilities, CoolCAD is innovating in semiconductor device modeling and simulation for cryogenic environments. Temperature-induced effects can alter material and device behavior unpredictably, making accurate modeling essential for reliable low-temperature device design. CoolCAD's simulation tools help engineers anticipate how different materials and design choices will respond in cryogenic conditions, supporting a holistic approach to cryogenic electronics and enabling the development of optimized, reliable devices.

CoolCAD Electronics also emphasizes the importance of understanding materials science and device physics for successful cryogenic electronics. The company's experts work closely with researchers, engineers, and institutions to bridge fundamental materials research and applied

device engineering. This collaborative approach drives the development of novel semiconductor materials, such as high-k dielectrics, essential for cryogenic circuit performance. CoolCAD's solutions help create devices that operate efficiently in demanding cryogenic regimes by understanding material interactions with the environment. The company's work is especially relevant to quantum computing, where precision and reliability are critical for the stable operation of qubits and other low temperature components. CoolCAD's testing platforms help ensure these devices operate as intended at the cryogenic temperatures required for quantum operations. By providing a detailed understanding of device behavior at ultralow temperatures, CoolCAD advances the performance and scalability of quantum technologies, which rely on precise quantum state control. [www.coolcadelectronics.com](http://www.coolcadelectronics.com)



Leading Supplier of Cryogenic Interconnect Products

# Cryogenic Component and Cabling Solutions

**CryoCoax** specialises in the design and manufacture of cryogenic interconnect products for customers around the world and for a very diverse range of applications and industries.

Here are just some of our capabilities:

- Standard cable materials available: Cupronickel, Beryllium Copper, Niobium Titanium & Stainless steel (Silver plated & more options available on request)
- Connector options: SMA Plugs & bulkhead jacks, 2.9mm Plugs & bulkhead jacks, SMP female Solderless & Non-magnetic options available
- Straight & formed cable assemblies to customer requirements
- Sealed Adaptors
- Hermetic Connectors and Adaptors
- Attenuators
- Low Temperature Hardware
- Full coaxial stick manufacturing. RF testing to 43GHz. Cold temperature & leak testing capabilities



For more information, please contact one of our sales teams:

[info@cryocoax.com](mailto:info@cryocoax.com)  
[www.cryocoax.com](http://www.cryocoax.com)

USA: +1-(931) 707-1005  
UK: +44 (0) 1245 347145

[info@intelliconnectusa.com](mailto:info@intelliconnectusa.com)  
[info@intelliconnect.co.uk](mailto:info@intelliconnect.co.uk)




# WCS Redefines Boundaries in Cryogenics

by Dr. Carl S. Kirkconnell, P.E., President, West Coast Solutions

West Coast Solutions (WCS) has experienced remarkable growth since its founding in 2015 by Dr. Carl Kirkconnell. From its origins as a one-person operation, the company has expanded to a team of over 40, 80% of whom are engineers. Anchored by a core group of seasoned professionals—many former Raytheon colleagues—and bolstered by a dynamic team of early-career engineers, WCS has cultivated a unique balance of experience and innovation. Cryogenics remains a central focus, reflecting Dr. Kirkconnell's expertise in the field. This foundation, combined with technical adjacencies, has enabled WCS to establish three thriving business sectors: cryogenics, aerospace and electronics and power.

Within the cryogenics community, WCS is best known for its high-performance, cost-effective, radiation-hardened cryocooler control electronics (CCE) designed for airborne and spaceflight applications. While many projects remain confidential, notable contributions include the NASA EXCITE (Exoplanet Climate Infrared Telescope) program. For this mission, WCS delivered two sets of cryocooler electronics to drive and control Thales LPT 9310 pulse-tube cryocoolers on a balloon-based platform. In addition to providing the flight electronics, WCS supported real-time tuning of the exported vibration minimization servo—a technical achievement detailed in Cryocoolers 23. Similarly, WCS played a pivotal role in supporting Creare's MCCE-TS manufacturing effort for L3Harris Technologies' Tranche 0 (T0) and hypersonic and ballistic tracking space sensor (HBTSS) programs.

WCS's capabilities in cryogenics extend far beyond cryocooler electronics. As detailed in Cryocoolers 21, the company served as the cryocooler system architect for the Hawaii Space Flight Laboratory's hyperspectral thermal imager (HyTI) program. This involved developing the mechanical integration scheme, performing the thermal design, assessing exported vibration effects and delivering cryocooler flight electronics. The success of HyTI led to WCS's selection



HyTI – CCE and Cryocooler Integration for HSFL HyTI. Credit: WCS

as the CCE supplier for HyTI-2. Recent advancements also include performing exported force and torque (EFT) measurements using the company's 6-DOF "Kistler table" dynamometer, evaluating the cooling performance of commercial off-the-shelf cryocoolers under high-vibration conditions and leading the design of next-generation cryocoolers to meet emerging requirements. In essence, WCS serves as a comprehensive cryogenics expert, offering expertise spanning from cryocoolers and their integration to CCEs tailored for specific applications.

The company's ventures into aerospace electronics have evolved organically from its cryogenics work, drawing on decades of experience with space infrared sensors from the team's Hughes and Raytheon roots. Building on its success with CCEs, WCS has developed a robust focal plane electronics (FPE) portfolio, achieving technology readiness level (TRL) 9 in this area. The company has also delivered custom power distribution electronics for flight programs with complex infrared sensor demands and is currently designing thermal control electronics for another space mission. Collaborations with Creare have further broadened WCS's portfolio, such as the development of high-accuracy sensing electronics for a next-generation spacesuit oxygen flowmeter. This blend of rapid design capability, adaptability and radiation-hardening expertise has

positioned WCS as a leader in aerospace electronics, expanding its impact well beyond its origins in cryogenics.

Completing WCS's triad of capabilities is its growing power portfolio. Among its most notable achievements is the TRL 6 flight qualification of the hybrid battery supercapacitor (HBS) for the Missile Defense Agency. By hybridizing battery and supercapacitor electrodes within a single core, WCS—collaborating with a local battery cell manufacturer—has pioneered a novel space battery with approximately three times the power density (~450 W/kg) of standard lithium-ion competitors. This compact 1U (10x10x10 cm) unit delivers a continuous 700W for over six minutes, unlocking a new class of high-power payloads for satellites. Applications include supporting large long-wave infrared (LWIR) and very longwave infrared (VLWIR) sensors in duty-cycled orbits, synthetic aperture radar (SAR), electric propulsion, high-data-rate transmitters and directed energy systems.


WCS redefines industry standards through advances in cryogenics, aerospace electronics, and power technology. The company's multidisciplinary expertise and commitment to excellence ensure its position as a trusted partner for solving the complex challenges of modern space and defense missions. [www.wecoso.com](http://www.wecoso.com)





## Advancing Cryogenic Measurement

Precision products ▶  
for reliable cryogenic  
measurement and cooling



### Temperature Sensors

Cernox® RTDs, diodes, and specialty types •  
<10 mK to over 1500 K • flight-qualified versions •  
wide selection of mounting packages available



### Temperature Controllers and Monitors

Purpose built for cryogenic sensor measurement •  
current reversal eliminates thermal EMF offsets •  
up to 100 W of PID control • LabVIEW™ drivers available



### Laboratory Cryostats

LN<sub>2</sub>, LHe, and closed-cycle refrigerator models •  
cooling for ultra-high vacuum environments •  
application-specific and customized solutions



### Recirculating Gas Coolers

Cryogen-free cooling for continuous flow cryostats •  
fast sample changes without warming up the system •  
ask us about new fully automated Infinite Helium model

# ° BLUE FORS

## Enabling Quantum Technology, Physics Research, and Life Sciences.

From cryocoolers to liquid helium management, our Cryomech products cover all your low-temperature experimental needs.



**CRYOMECH**



**PT450 Pulse Tube Cryocooler**  
5.0 W @ 4.2 K w/ 65 W @ 45 K



**LHeP28 Liquid Helium Plant**  
≥28 L/Day



**AL630 Gifford-McMahon Cryocooler**  
100 W @ 20 K

**BLUEFORS.COM**





## Design Considerations for Cryogenic Supports

Supports used in low temperature or cryogenic systems have several factors that are part of the design considerations. First, the supports must be capable of carrying all the expected mechanical loads. Complications exist because of the extreme temperature difference that usually accompanies these support structures. The temperature differences must consider heat load to the cold mass and any thermal contractions during cooldown. In most situations, the supports are also required to withstand shipping transportation loads, which can either be under warm or cold conditions. Figure 1 shows examples of many common support designs.

This article provides an overview of some of the factors which must be considered in the design of cryogenic supports and some examples of common applications. A more comprehensive discussion of support structures used in cryogenic applications can be found in our first references.<sup>[1,2]</sup>

### Thermal and Mechanical Considerations

Structural supports for cryogenic equipment must sustain the required loading under tension or compression as well as thermal stresses. Mechanical loads for structural supports are developed by tension and compression along a member's axis, bending, and torque or twisting. Lateral loads are also present in applications such as superconducting accelerator magnets as described in Nicol,<sup>[3]</sup> and Nieman et al.<sup>[4]</sup> which can introduce bending and twisting. Loading can be present from several sources, including the weight of the cold mass, thermal contractions, and shipping loads. In some situations, the cold mass may be provided with additional shipping supports that will be removed after the device has been installed. The mechanical load carrying requirement is often in conflict with the minimization of heat transfer to the cold mass.




Figure 1. Simplified sketches of cryogenic supports, which thermally isolated various cold-masses from outer vessels at environment temperatures. 1,2,4 and 5: Tension and compression rods. 3 and 6: Tension and compression post. 7: Ring shaped support, 8: Horizontal tension bars. 9: Neck tube support. Credit: Shu and Demko

This discussion is not intended to be comprehensive of the mechanics of materials and stress calculations, but only to provide an overview of stress considerations needed in the design of supports. The designer should consult more comprehensive references such as Beer<sup>[5]</sup> and Shigley<sup>[6]</sup> for more complete discussions of stress analysis.

### Materials

The selection of materials used in cryogenic applications depends on compatibility with low temperatures.<sup>[5]</sup> Many materials become brittle when they are cooled below their glass transition temperature. Some of these materials include metals such as iron,

carbon and low alloy steels, molybdenum, niobium and zinc. In general, most body centered cubic (bcc) metals, and most plastics become brittle at low temperatures. The commonly available polyvinyl chloride (PVC) pipe is commonly used to replace piping at room temperature, but PVC is very brittle at low temperatures and should be avoided.

Acceptable materials include body centered cubic structure (bcc) metals such as copper, nickel, copper-nickel alloys, aluminum and its alloys and austenitic stainless steels, titanium, and zirconium remain ductile at low temperatures. In general face-centered cubic (fcc) metals remain ductile.

► continues on page 80

Materials such as polytetrafluoroethylene (Teflon™), also remain ductile at low temperatures.

High vacuum is often used as part of the thermal isolation, so metals must provide the capability to maintain high vacuum inside the vessel. Outgassing of hydrogen trapped in stainless steels during the formation process is usually accounted for through getters in the vacuum space. In some applications, corrosion resistance is also needed.

Many composites are used due to the ability to tailor thermal and strength properties. These tend to be more porous than metals and have the potential to outgas. The fiberglass composites, such as G-10 and G-11, are widely used because of their strength, low thermal conductivity, very low outgassing and for many applications their dielectric strength. Kevlar straps have been applied in some situations because of the high strength.

### Thermal Optimization

Thermal optimization of a support system seeks to balance the load-carrying capability of the support with the competing factor that the support structure minimizes the heat load during operation. There are many approaches available that rely on the choice of high strength low thermal conductivity materials and the location relative to the cold space. In other more complex situations, heat stations can be used to reduce the heat load to the coldest part of the system.

Barron<sup>[6]</sup> provides an example of a composite support link used in some support systems for cryogenic fluid storage vessels as shown in Figure 2. Using a particular set of material properties, he shows that the heat transfer for arrangement A, with the fiberglass on the cold side, is 120.9 mW and for arrangement B, with the stainless steel on the cold side, the heat load is 111.9 mW or a 7% decrease due to the placement of the materials. Other factors, such as the length of the tubes, will also have an effect.

In situations where a support is a direct connection between a room temperature outer structure and a cold mass, heat intercepts at various location along the member




Figure 2. Example of a structural support indicating the effect of the material arrangement on the heat load. Credit: Demko and Shu




Figure 3. Uniform support between room temperature,  $T_1$ , and liquid helium temperature,  $T_4$ , with two heat stations at intermediate temperatures  $T_2$  and  $T_3$ . Credit: Demko and Shu




Figure 4. Calculated Carnot power for varying second heat station temperatures at the optimum locations along the support. Credit: Demko and Shu






Figure 5. Flexible vacuum jacketed line supports and insulation. Credit: Demko and Shu




Figure 6. (A) and (B) Rigid vacuum jacketed line supports. (C) Nested vacuum jacketed transfer lines. Credit: Demko and Shu

are often used. The temperature stations depend on various system constraints, such as if using a cryocooler which may have specified heat stages. Another way that was described by McAshan relies on minimizing the Carnot refrigeration power. This simple but very instructive analysis was performed by McAshan for the Superconducting Supercollider (SSC) cryogenic system.<sup>[1,7]</sup> It assumes a uniform cross-section member with heat stations as an example. The

optimization is based on the fact that the power needed to remove a heat load at a given temperature decreases as the temperature increases. In this memo, McAshan performs an optimization of the refrigeration requirements along a stainless steel (UNS S304000) and an Ultem-2100 support assuming uniform cross-section, and variable thermal conductivity with heat stations at two locations along the post. The uniform cross-section simplifies the analysis but is

a reasonable assumption since it is the mechanical load that determines the area of the support. The optimization clearly shows that refrigeration requirements can be minimized for the 4 K level with heat stations around 80 K and 20 K.

The situation is illustrated in Figure 3 for a case with two heat stations. The cross-sectional area of the support,  $A$ , is assumed

► continues on page 82




Figure 7. Sketch and photo of the SSC magnet post. Credit: Nicol

to be constant. This would most likely be the case since the area would be determined by the stresses in the member. The total length of the support is  $L$ , which is broken into segments  $L_1$ ,  $L_2$ , and  $L_3$  which separates the heat stations at the different temperatures. The thermal optimization is performed by minimizing the Carnot refrigeration power,  $P_{Carnot}$ , needed for this member.

The solution shows that the distance along the support at which a heat station is located depends on the temperature of the heat station. The Carnot power at the optimized locations for this support is provided in Figure 4. The first stage or warm heat station was assumed to be at temperatures of 70 K, 80 K, and 90 K.

### Examples of Support Structures

There are many different cold masses that can be used as examples. The vacuum jacketed pipe is widely used in most cryogenic fluid distribution systems. Heavy cold masses, such as accelerator magnets, frequently experience complex combined stresses (vertical, shear and bending moments) which provides examples of the wide range of support structures that are needed in cryogenic systems.

### Vacuum Jacketed Line Pipe Supports

A vacuum jacketed line pipe support is used to hold the outer vacuum enclosure separate from the cold inner pipe. Pipe supports have different structures depending on whether the pipe is a flexible line or rigid.

A description of the design of a flexible line and some methods of measuring the thermal performance are described in Knoll.[10]

### Reentrant Post Magnet Support

The unique and sophisticated reentrant post design is for the suspension system of Superconducting Super Collider (SSC) dipole magnets to meet the rigorous thermal and structural requirements. The design is shown in Figure 7. First, it resists structural loads imposed on the cold mass assembly, ensuring stable operation over the course of the magnet's operating life. Second, it serves to insulate the cold mass from heat conducted from the environment. The evolution and selection of the suspension system for SSC magnets has been well documented by Nicol, Nieman et al.[3,4]

The magnet assembly is supported vertically and laterally at five places along its length. To accommodate axial shrinkage during cooldown, the magnet assembly is free to slide axially at all but the center support. The center serves as the anchor position. The cylindrical post constructed with fiber reinforced plastic (FRP, such as G10 and G11) tubing and having metallic heat intercepts and end connections.

### Summary

A brief description of the factors which must be considered in the design of supports for cryogenic applications: The requirement for strength conflicts with minimizing the heat load to the cold mass. In some situations, this can be mitigated through careful

selection and placement of materials. Other, more complicated systems may rely on removing heat at higher temperatures along the structure with heat stations. The placement of these can also be arranged to minimize the refrigeration load on the system.

#### References

- [1] Demko, J., Fesmire, J. and Shu, Q.S. *Cryogenic Heat Management, Technology and Applications for Science and Technology*.
- [2] Shu, Q.S., Demko, J. and Fesmire, J. "Developments in Advanced and Energy Saving Thermal Isolations for Cryogenic Applications." *IOP Conference Series: Materials Science and Engineering*, 2015.
- [3] Nicol, T., et al. "Design and Analysis of the SSC Dipole Magnet Suspension System." *International Industrial Symposium on the Super Collider (IISCC)*, 1989.
- [4] Nieman, R.C., Gonczy, J.D., Nicol, T. et al. "1985 Design, Construction, and Performance of a Post Type Cryogenic Support." Fermilab TM-1349, September 1985.
- [5] Beer, F., Johnston, Jr., D., DeWolf, J. and Mazurek, D. *Mechanics of Materials*. Sixth Edition, McGraw-Hill, 2012.
- [6] Shigley, J. and Mitchell, L. *Mechanical Engineering Design*. Fourth Edition, McGraw-Hill Book Company, 1983.
- [7] Flynn, T. *Cryogenic Engineering*. Marcel Dekker, New York, 2005.
- [8] Barron, R.F. *Cryogenic Heat Transfer*. Taylor and Francis, 1999.
- [9] McAshan, M. "Optimization Studies for the Conceptual Design of the SSC Cryogenic System." Internal Communication, 1986.
- [10] Knoll, D. et. al. "Evaluating Cryostat Performance for Naval Applications." *AIP Conference Proceedings*, vol. 1434, pp. 265-272, 2012. doi: 10.1063/1.4706929.





## Advanced Thermal Insulation Systems for Low Temperature Applications, Part 3 (Engineered LH<sub>2</sub> System Examples)

### Cold costs money, and insulation saves money

Insulation also makes possible the practical control and operation of cryogenic systems. It is the first line of defense in beating the heat and meeting the challenges of conveying liquid hydrogen (LH<sub>2</sub>) for mobility, energy storage, and industry. This includes a wide range of electrical power equipment, aircraft, ships, spacecraft, trucks, tractors, and other heavy machinery being developed in the clean energy transition currently underway.

In Part 1 of this series, the needs and motivations for different cryogenic insulation applications, key parameters and definitions, calculations, and the basics of cryostat testing were introduced. Part 2 provided cryostat test data for key examples of thermal insulation systems and thermophysical data for structural-thermal materials used in cryogenic systems. The “cold triangle design” approach was also reviewed. Concluding this series, Part 3 examines engineered system examples of different LH<sub>2</sub> tanks and piping, including a breakdown of the components of total heat transmission.

Five examples of cryogenic systems—three tanks and two piping systems—are shown in Figure 1. In each case, the optimum approach involves a unique combination of materials; for simplicity and comparison, uniform hot and cold surfaces are assumed. The cold vacuum pressure (CVP), ranging from high vacuum (<0.1 μ), to normal vacuum (~1 μ), to moderate vacuum (~10 μ), to soft vacuum (~100 μ), to no vacuum (760,000 μ), is also uniquely representative of actual working systems in each case. (Note: 1 millitorr = 1 μ = 0.0013 mb.)

### Comparative Analysis of Example Systems

The first example is a 125-m<sup>3</sup> horizontal cylindrical SST tank with a carbon steel outer jacket and a 200-mm annular space. This factory-built, medium-sized tank includes an 80-layer MLI system for high vacuum, four G10 pad supports, several piping penetrations, and a 0.6-m diameter manway for internal access and multiple instrumentation feedthroughs. Extensive boiloff testing was performed using both LN<sub>2</sub> and liquid hydrogen (LH<sub>2</sub>).

The second example is a 3,200-m<sup>3</sup> spherical 304 SST tank (30-mm thickness) with a carbon steel outer jacket (17-mm thickness) and a 1,200-mm annular space. This tank includes 40 vertical SST support rods connecting the inner vessel to the outer jacket, four piping penetrations on the bottom, and a 0.5-m diameter manway for internal access. The specified boiloff rate is 0.075% per day (LH<sub>2</sub>) with the original perlite powder insulation. In this example, the insulation system is glass bubbles, which provides an estimated 46% reduction in boiloff, compared to perlite, at a moderate vacuum level of 10 millitorr, based on field test data. Construction of an even larger LH<sub>2</sub> storage sphere (4,700 m<sup>3</sup>), including the glass bubbles insulation system, was completed at NASA's Kennedy Space Center in 2022.

The third tank example is a 100-liter carbon composite tank in a 4:1 cylindrical geometry with an SST outer jacket and an annular space of 23-mm thickness. The LCI system is designed for a soft vacuum of 100 μ for low cost and to avoid vacuum maintenance. Three polyimide aerogel rings support and isolate the inner vessel, and a single 12.7-mm diameter piping penetration

is also included, as depicted for this generalized mobility tank concept.

In addition to the three tanks, two piping systems are analyzed. Example four is a DN<sub>2</sub>5x80-mm all-SST vacuum-jacketed (VJ) pipe segment with an 18.3-m length. The ends are thermally guarded with LN<sub>2</sub> to achieve an absolute boiloff test. The insulation consists of 20 layers of MLI (aluminized Mylar and paper) with a CVP in the normal vacuum range of approximately 1 μ.

Finally, example five is a DN<sub>2</sub>50x300-mm, double-walled field joint connection (1-m overall length) between two VJ pipe segments. The ends, with 425-mm length cones, act as supports, while a straight middle portion is 150 mm in length. The insulation system is a complete bulk-fill using aerogel particles (1-mm nominal diameter) in the sealed annular space, designed for non-vacuum. The space is optionally backfilled with CO<sub>2</sub> to enhance performance at a cryo-pumped soft vacuum (~100 μ) under cold operating conditions.

Breakdowns of the heat leaks for the five example systems are summarized in Table 1. The Q total is the sum of four parts: Q<sub>i</sub> is the heat leak for the insulation; Q<sub>s</sub> is the heat leak attributed to the supports; Q<sub>p</sub> is the heat leak due to the piping penetrations; and the additional Q<sub>iQF</sub> is the heat leak associated with the installation quality factor (IQF). The total system thermal conductivity (k<sub>s</sub>), as defined in ASTM C1774, is also calculated for each case.

The best thermal insulation system under idealized laboratory conditions is not always the best one to use in practice. In the example of the field joint, the majority of the

► continues on page 84




Figure 1. Cryogenic system examples: 1) cylindrical tank (upper left), 2) large spherical tank (upper right), 3) small composite automotive tank (middle), 4) launch tower transfer piping (lower left), 5) piping field joint (lower right). Credit: J. Fesmire



**Table 1. Total heat flow rate analysis for different examples of cryogenic systems**

Case	Cryogenic System Description	Thermal Insulation System	CVP	Dimensions		Components of $Q_{total}$								$Q_{total}$ W	$q$ W/m <sup>2</sup>	$^{\dagger}k_s$ mW/m-K
				$t$	$^*A_e$	$Q_i$		$Q_s$		$Q_p$		$Q_{IQF}$				
				$\mu$	mm	m <sup>2</sup>	W	%	W	%	W	%	W			
1	Medium tank, VJ, factory built (125-m <sup>3</sup> capacity)	MLI (80 layers) for high vacuum	<0.1	250	229	101	33.7	50	17	130	43.3	19	6.3	300	1.3	1.5
2	Large tank, VJ, site-built (3,200-m <sup>3</sup> capacity)	Bulk-fill glass bubbles for moderate vacuum	10	1200	1194	178	74.1	31	12.9	31	12.9	0	0.0	240	0.2	1.1
3	Small composite tank, VJ, conceptual (0.1-m <sup>3</sup> capacity)	LCI for soft vacuum	100	23	1.6	10	68.9	3	21	1.5	10.4	?	?	14.4	9.0	1.0
4	Piping System, DN25x80-mm, VJ, with two bayonet joints, factory built (18.3-m length)	MLI (20 layers) for normal vacuum	1	26	3.2	2.5	12.0	3.2	15	8	38.3	7.2	34.4	20.9	6.5	0.8
5	Piping Field Joint, DN250x300-mm, double-wall, field fabricated (1-m length)	Bulk-fill aerogel for non-vacuum (optional CO2 cryopumped)	760000	50	0.88	26.5	54.1	13	27	9.5	19	0	0.0	49.0	55.7	12.9

\*Effective surface area between inner and outer shells (log-mean area)

<sup>†</sup> $\Delta T = 293\text{ K} - 78\text{ K} = 215\text{ K}$

Note: 1 millitorr = 1  $\mu$  = 0.0013 mb

heat leak is fixed by solid conduction (75% of Q total), and the annular space is mostly inaccessible for wrapping with multilayer insulation (MLI). Added to the geometric constraints are the challenges related to field fabrication, for which achieving a long-term high vacuum in the annular space is not a reasonable expectation. With the option of adding a CO<sub>2</sub> backfill to achieve the effect of cryopumping to a soft vacuum, the Q total drops to 30.6 W, and the ks drops to 8.1 mW/m-K, making it comparable to a high-vacuum MLI system in this case.

These cases represent idealized solutions for each situation. The  $Q_{IQF}$  ranges from zero to 34% of the total. In many real cases, the  $Q_{IQF}$  can be as high as or higher than the  $Q_i$ . For example, a small single penetration (12-mm diameter) through an MLI blanket results in a  $Q_{IQF}$  that is one to five times the  $Q_i$ . Even in bulk fill systems—where the two examples given show zero IQF—there can still be issues. Two identical design 3,200-m<sup>3</sup> VJ LH<sub>2</sub> storage tanks were built at Kennedy Space Center in 1965, but

one ended up with more than triple the heat leak of the other (3.8 versus 1.1 m<sup>3</sup> per day boiloff losses). The problem was eventually traced to a large void within the perlite annular space filling. Therefore, the  $Q_{IQF}$  is not just a deviation from the ideal or a degradation of the insulation material that can be mitigated; it represents a substantial heat leak potential that must be addressed up front in the design process.

The elements are highly interdependent, showing that the analysis of the total heat leak is an iterative process. A practical methodology for designing cryogenic thermal insulation systems is based on a “cold triangle” approach of insulation, supports, and piping, as well as the insulation quality factor (IQF). The total heat leak of the end product is what matters, but to minimize this heat leak cost-effectively, the calculations, testing, and materials data must be covered, and the thermal performance understood as a summation of its parts. The approach also provides a basis for evaluating the performance benefits of new materials and

analyzing cost-effectiveness in overall system design. Examples of different cryogenic storage tanks and piping systems show the relative importance of both insulation and structural materials in achieving designs with the highest energy efficiency. The right design approach depends on the shape, size, operational duty cycle, and, of course, the thermo-economic objectives.

References:

[1] Fesmire, J., & Swanger, A. (2019). Advanced cryogenic insulation systems. *25th IIR International Congress of Refrigeration*, Montreal, Canada, IIR No. 1732.

[2] Demko, C., Fesmire, J., & Shu, H. (2022). *Cryogenic Heat Management: Technology and Applications for Science and Industry*. CRC Press, imprint of Taylor & Francis Group.

[3] Fesmire, J., Swanger, A., Jacobson, J., & Notardonato, W. (2021, July). Energy efficient large-scale storage of liquid hydrogen. *Advances in Cryogenic Engineering*, Cryogenic Engineering Conference.

[4] Notardonato, B., Swanger, A., Fesmire, J., Jumper, K., Johnson, W., & Tomsik, T. (2017). Final test results for the ground operations demonstration unit for liquid hydrogen. *Cryogenics*, 88, 147–155.

# CRYOGENIC REFERENCES

## Explore CSA’s List of Cryogenic References

CSA provides a list of cryogenic references, including conference proceedings, journals, periodicals, books, websites and more. The references are available online and as a PDF. Click through now to discover something new and be sure to contact editor@cryogenicsociety.org to recommend additional resources.

[www.cryogenicsociety.org/cryogenic-references](http://www.cryogenicsociety.org/cryogenic-references)

# Stirling Cryogenics' World Tour

by Francesco Dioguardi, Stirling Cryogenics

Given the theme of this issue of *Cold Facts*, Stirling Cryogenics would like to take you on a tour of our 70-year history, telling about our recent and vintage cryogenerators and systems all around the world.

Universities worldwide have been our customers from the very beginning, cheering in the 1950s that they could now produce their own LN<sub>2</sub>. In South America, proud examples include systems at the Universidad de Chile since 1964 and IVIC in Venezuela where the old Philips Cryogenerator was replaced with a new system after 45 years of operation. The University of Buenos Aires in Argentina has several systems in operation of which the oldest cryogenerator was installed in 1958 providing 66 years of service!

A high-level LN<sub>2</sub> system worth mentioning is the one installed at Atacama Large Millimeter Array (ALMA) of ESO at Paranal in the Atacama Desert in Chile, at an altitude of 2635 meters above sea level.

Moving from South America to Africa, here the two main types of applications are the preservation of biological materials and production of fruit juices and water. Throughout Africa there are institutes that carry out research on viruses, for example, which are preserved in LN<sub>2</sub>. As these often are in remote locations, they depend on Stirling LN<sub>2</sub> generators.

Renowned beverage companies making drinks often use Stirling systems to provide LN<sub>2</sub> for their nitrodosers, injecting a drop of liquid nitrogen into a bottle of juice, water or oil. The rapidly evaporating liquid nitrogen will disperse the oxygen from the bottle, extending its shelf life without preservatives and increasing compressive strength of bottles required during packaging and transportation.

Crossing the Middle East with many systems at universities, we land in India. Beyond a large number of closed loop cooling systems in many of India's renowned science and technical institutes and universities,



**Stirling Cryogenics' dedicated team at Hysytech's 20th anniversary and inauguration of its new headquarters in Orbassano, Italy. Credit: Stirling**



**Onsite liquid nitrogen for storage and preserving semen for artificial insemination. Credit: Stirling**

India is also home to a large number of LN<sub>2</sub> systems for artificial insemination. These are used to preserve semen for breeding livestock and assuring milk production, for which many centers are in the countryside.

India is by far the country with the largest number of Stirling systems, many of which date back to the 1990s and are still in operation, for example systems at IIT

Kharagpur installed in 1994 and at NEHU where our LN<sub>2</sub> system was installed in 1999.

Moving further east, we find again more systems for AI all over Asia and closed loop systems for superconductivity in Korea and Japan. Crossing the ocean brings us to North America. Here too we have LN<sub>2</sub> systems at universities in the US and a large customer base concentrated in the east of Canada.

► continues on page 88





CRANE

Vacuum Jacketed Piping Systems | Cryogenic Transfer Hoses | Phase Separators | Automatic Fill Stations | Manual + Actuated VJ Valves | OEM & Private Label Manufacturing



COMPLETE CRYOGENIC SOLUTIONS FOR ALL APPLICATIONS

www.technifab.com | 812.442.0520 | sales@technifab.com

SAFETY KITS and SAFETY KITS PLUS FOR COMMERCIAL CRYOGENIC APPLICATIONS

TEMPSHIELD® CRYO-PROTECTION®

CRYO-PROTECTION® SAFETY KITS - FOR LABORATORY APPLICATIONS

Kits contain: Mid-arm or elbow gloves 42" or 48" apron Fully adjustable face shield One-size gaiters\* fit most (\*for Plus kits)

CRYO-INDUSTRIAL® SAFETY KITS - FOR HEAVIER-DUTY APPLICATIONS

CE CAT. III + CAT. II\*\* \*\*face shield

info@tempshield.com 207-667-9696 TEMPShield.COM



PART OF OPW COMPANY

TRUSTED SINCE THE BEGINNING

CPC-Cryolab valves have powered advancements in cryogenics for generations, setting new benchmarks in low-temperature applications. From cryo tanks to distribution systems, trust our products ensure safety, efficiency, and reliability, custom tailored to your specific needs.

Rockwood Swendeman

Also try simplifying installation, cut costs, and enhance safety through versatile applications in liquid and gaseous cryogenic systems with our Rockwood-Swendeman safety relief valves.

(813) 644 - 3764

sales@cpc-cryolab.com

www.cpc-cryolab.com



With numerous scientific institutes and innovative companies, closed loop systems can be found in many of the states. Our deepest system is at the Sanford Underground Research Facility, located at a depth of 1,500 meters in South-Dakota. Aiming higher are our systems supporting space research at NASA and Georgia Tech. Another application which we support widely is superconductivity, with 25 K systems at CAPS in Florida and ComEd in Chicago for their HTS cable in use since 2021.

If we cross the Atlantic again, we come close to home with the 22 K GHe loop cooling system for the Reactor Institute Delft in the Netherlands, making sure their neutron moderator existing of a bath of LH<sub>2</sub> will always be kept at the right pressure.

Similar systems are being built to cool superconducting electric motors that are now under development in Europe, paving the way for carbon-free and sustainable aviation.



Stirling Cryogenics liquid nitrogen system at Universidad de Buenos Aires - Argentine dated 1958. Credit: Stirling

Sustainability is a relatively new but growing market which is supported by Stirling, providing cryogenerators and systems to convert bio-mass into bio-LNG, which can be used as a CO<sub>2</sub> neutral fuel for trucks. By the end of 2024, the collective of our LNG liquefiers across Europe will be producing over 150 tonnes per day of bio-LNG, replacing diesel and fossil LNG, with

more projects being developed in the coming years.

The latest application we support is the emerging market of liquid hydrogen, providing systems to produce LH<sub>2</sub> on site, as well as manage boiloff by reliquefaction, for which in fact we have been building cryogenerators since the late 1960s.

In the spirit of "Cryogenics around the World," the final application we would like to showcase is our seaworthy version of cryogenerators for reliquefaction of LNG on ships, as these quite literally move around the world.

We at Stirling Cryogenics hope this tale of the use of cryogenics and cryogenerators around the world and through time has given you an insight into Stirling's past, present and future. Obviously not all systems and applications have been mentioned. For any inquiries on these or other possibilities, please contact us. [www.stirlingcryogenics.com](http://www.stirlingcryogenics.com)

**FIND QUALITY EMPLOYEES THROUGH CSA!**  
*Advertise your job openings to a pre-selected audience.*

The CSA features prominently in Google searches for "cryogenic jobs." Take advantage of our standing.  
Help Wanted ads are FREE to Corporate Sustaining Members.  
Others pay \$100-\$200 depending on duration of listing.  
Individuals can post their resumes FREE.  
Submit your help wanted ad or resume at <https://2csa.org/jobs>

**FLEXIBLE LIQUID NITROGEN PIPING**

- Highly Efficient Semiflex®/Triax
- Rugged & Adaptable - fits an array of applications
- Industry Leading Sales & Support

Guaranteed to satisfy your application

**VACUUM BARRIER VBC**  
Woburn, MA 01801, USA | 781-933-3570  
[sales@vacuumbarrier.com](mailto:sales@vacuumbarrier.com) | [vacuumbarrier.com](http://vacuumbarrier.com)





## NEXUS OF CLEAN™

"Chart's vision is to be the global leader in the design, engineering and manufacturing of cryogenic process technologies and equipment for the Nexus of Clean™ — clean power, clean water, clean food and clean industrials, regardless of molecule."

*Jill* JILL EVANKO / CEO / CHART INDUSTRIES

# CLEAN CLEAN CLEAN CLEAN

CHART DELIVERS CLEAN SOLUTIONS FOR

⚡ Power   💧 Water   ✂ Food   ⚙ Industrials

🔍 Learn more at [chartindustries.com/esg](https://chartindustries.com/esg)



# Product Showcase

This Product Showcase is open to all companies and related manufacturers offering new or improved products for cryogenic applications. We invite companies to send us short releases (150 words or fewer) with high-resolution JPEGs of their products to [editor@cryogenicsociety.org](mailto:editor@cryogenicsociety.org).



## ICEoxford Cryogen-Free (Dry Cryogenics) System

A cryogen-free (or DRY) system achieves cryogenic cooling without liquid cryogenics such as liquid nitrogen or helium. Instead, these systems use a coldhead to lower temperatures, liquefying helium to 4 K; pressure reduction enables cooling to below 1 K. Cryogen-free systems offer several advantages: they're often more compact and eliminate the need for costly cryogenic liquids and safety measures related to vapor boiloff. Ideal for fields like material or medical research, these systems allow researchers to focus on their work without needing specialized cryogenic training. In space applications, cryogen-free systems also eliminate liquid handling and boiloff venting, making mission duration dependent on cryocooler reliability rather than cryogen volume. ICEoxford manufactures reliable cryogen-free superconducting magnets and systems, supporting research institutions worldwide with expert knowledge and dependable technology. [www.iceoxford.com](http://www.iceoxford.com)

## ACME Cryogenics

### XL Bore Vacuum Jacketed Piping

ACME Cryogenics, part of OPW Clean Energy Solutions, has launched its XL Bore Vacuum Jacketed Piping (VJP), designed to enhance cryogenic liquid transfer by reducing heat leaks and maintaining extremely cold temperatures. Unlike foam-insulated piping, this VJP uses a multi-layer insulation (MLI) system with metallic coatings that block radiative heat transfer, making it more durable and maintenance-free for over 20 years. Available in larger configurations—16" x 18", 20" x 24" and 24" x 28"—the XL Bore VJP ensures efficient handling of cryogenic liquids such as LNG, LH<sub>2</sub>, LOX, CO<sub>2</sub> and helium. Built in 40-foot segments, the piping system supports high-volume cryogenics applications, offering improved flow rates, enhanced cooling efficiency and cost-effectiveness compared to traditional methods. This robust design delivers superior insulation, higher flow rates and customizability to meet diverse industry needs in sectors like space exploration and fuel transport. [www.opwglobal.com](http://www.opwglobal.com)



## STAR Cryoelectronics

### Modular Four-Channel Quad SQUID and Quad Array Sensor Assemblies



STAR Cryoelectronics now offers two versions of a connectorized and modular four-channel SQUID sensor assembly with Nb shield and optional mu-metal shield that can be configured with four Series SQUID Array (SSA) sensors, four single SQUID sensors, or four two-stage SQUID amplifier sensor assemblies. The connectorized SQUID sensor packages simplify replacement in the field or changing SQUID type. Hermetic feedthroughs and mating cryocables are available with optional integrated heat sinks for installation in a variety of cryogenic systems, as well as input cables with superconducting shielding and superconducting twisted pairs. The Quad SQUID and Quad Array sensor assemblies can be read out using STAR Cryoelectronics single- or multichannel pcSQUID™ electronics. [www.starcryo.com](http://www.starcryo.com)



---

## Imtek Cryogenics

### CNPECO-1

The CNPECO-1 is the game-changer in liquid nitrogen production. With an impressive output of over 240 liters/day and industry-leading nitrogen purity at >99%, this compact powerhouse is built for efficiency. Consuming just 13 kW of energy, it redefines eco-friendly operations while slashing costs. Designed for simplicity, the plug-and-play setup and one-button operation make the CNPECO-1 as user-friendly as it is powerful. Its advanced cold-head technology ensures seamless, reliable performance, backed by a robust design and low-maintenance intervals of 8,000 hours. Perfect for medical, research and industrial applications, the CNPECO-1 fits effortlessly into any workspace with its compact size and low noise output (<65 dBA). The CNPECO-1 is the ultimate solution for liquid nitrogen generation—efficient, reliable and ready to deliver. Power your operations smarter, not harder. [www.imtekcryogenics.com](http://www.imtekcryogenics.com)



---

## Stirling

### Cryogenerators and Systems

Stirling Cryogenerators and systems are designed for a long life. Due to the robust design, some of our customers have been able to operate the Stirling Cryogenerator for more than 60 years. The only maintenance required is an annual inspection and cleaning. Once every 35,000 operating hours maintenance is required, which includes the preventive replacement of some parts. This maintenance is always carried out on-site by one of our service engineers. There is no need to ship components back to the factory for maintenance or repair, which means less downtime and transport costs. In addition, Stirling systems are equipped with a device that enables remote access to the control box. With this feature, we have the possibility to remotely support the customer in case of operational and maintenance issues. Stirling Cryogenics also offers service contracts, which cover a period of 6 years and include all annual maintenance. [www.stirlingcryogenics.com](http://www.stirlingcryogenics.com)

---

## CO2Meter

### Oxygen Deficiency Safety Alarm

The Oxygen Deficiency Safety Alarm is a 0-23% room oxygen monitor designed to protect staff from oxygen depletion. This device is designed to be mounted near nitrogen, argon, helium or other inert gas sources. It can also be used in walk-in refrigerators or freezers with temperatures as low as -50°C. Our Oxygen Deficiency Safety Alarm is used in laboratories, pharmaceuticals, cryogenics, process cooling, freezers, manufacturing and research facilities. [www.co2meter.com](http://www.co2meter.com)



# People & Companies in Cryogenics

Gas Equipment Company is excited to announce that **Christopher White** has joined our team as the new Sales Director for Industrial Gas and



Christopher White. Credit: Gas Equipment Company

Cryogenics. Chris' new role encompasses coordinating sales strategies across GEC's industrial gases and cryogenics division, with a focus on expanding product lines, enhancing client relationships and driving growth for the company. With a wealth of sales experience under his belt, Chris is eager and ready to take on his new role.

**Leon Cooper**, Nobel-winning physicist and neuroscientist whose groundbreaking contributions reshaped the industry's understanding of superconductivity and neural networks, passed away at the



Leon Cooper. Credit: Keystone Press/Alamy

age of 94. He co-developed the BCS theory, which explained how "Cooper pairs" enable resistance-free electricity in supercooled materials, earning the 1972 Nobel Prize in Physics. Later, he turned to neuroscience, co-creating the BCM theory, which modeled how brain activity adapts during learning, leaving a lasting impact on cognitive science and machine learning. A long-time professor at Brown University, Cooper's interdisciplinary work showcased the vital role of imagination in advancing physics, neuroscience and philosophy.



Image provided by Web Industries Inc.

Web Industries Inc., a composite materials converter and outsource manufacturer serving the aerospace, wire and cable, medical, home care and industrial markets, has named **Suzanne Rotherham** chief operating officer. Rotherham brings to Web Industries more than 25 years of business experience working with domestic and global companies. Her leadership roles span supply chain, information technology and general management. She has led several transformative initiatives, including ERP implementation. Rotherham joins Web Industries from Hollingsworth & Vose, where she served most recently as vice president and managing director for the Americas region. Prior to that, she spent six years at Johns Manville in a series of progressive leadership roles.

**Bluefors** officially opened an expanded facility in Syracuse, New York, increasing production capacity for Cryomech cryocoolers and enabling the manufacture of Bluefors Dilution Refrigerators directly in the USA. The expansion increases capac-



Bluefors Syracuse, NY opening. Credit: Bluefors

ity by 45% and doubles throughput to support the quantum sector and provide the cooling power needed in academia and industries such as medical and life sciences. The expanded facility also opens a new spare parts hub to serve customers in North America and lays the groundwork for the future growth of Bluefors operations in the USA.

A team of **University of Arizona** astronomers has unveiled new details about the nearly 100-billion-mile debris disk surrounding Vega, using **NASA's Hubble and James Webb space telescopes**. The observations reveal a remarkably

## Meetings & Events

### CCA 2025: International Workshop on Coated Conductors for Applications

March 11-13, 2025  
Geneva, Switzerland  
<https://indico.cern.ch/event/1347361/>

### 31st Space Cryogenics Workshop

May 13-15, 2025  
Incline Village, Nevada  
<https://spacecryogenicsworkshop.org>

### CEC/ICMC 2025

May 18-22, 2025  
Reno, Nevada  
[www.cec-icmc.org/2025](http://www.cec-icmc.org/2025)

### CRYOCO Cryogenic Engineering and Safety Course

July 14-18, 2025  
Golden, Colorado  
[www.cryocourses.com](http://www.cryocourses.com)


### 30th International Conference on Low Temperature Physics

August 7-13, 2025  
Bilbao, Spain  
[www.lt30.es](http://www.lt30.es)

### European Conference on Applied Superconductivity (EUCAS)

September 21, 2025  
Porto, Portugal  
<https://eucas2025.esas.org>

smooth disk of particles, with no evidence of large planets disrupting the structure. Webb detects warm, sand-sized grains close to the star, while Hubble captures smaller particles in an outer halo. The findings shed light on how dust



New details about debris disk surrounding Vega. Credit: NASA, ESA, CSA, STScI, S. Wolff (University of Arizona), K. Su (University of Arizona), A. Gáspár (University of Arizona)

dynamics vary across circumstellar disks and offer clues to planet formation. Vega's unique system contrasts with similar stars like Fomalhaut, raising questions about planetary system diversity and evolution. 🌌



## Hydrogen Getters for Cryogenic Vacuum Insulation



No activation required and no moisture generated! Vacuum Energy Getters ensure vacuum insulation lifetimes with outstanding performance and reliability (PG-HT-CRYO™ >250cc/g H<sub>2</sub> capacity)

For more information please contact us:

Email: [info@vacuumenergyinc.com](mailto:info@vacuumenergyinc.com)


Tel +1(216) 991 7000

[www.vacuumenergyinc.com](http://www.vacuumenergyinc.com)

"Exceptional Solutions for Exceptional Reliability"



## AMERICAN MAGNETICS



50+ years of experience  
Specializing in Cryogen Free & Custom Systems  
Recipient of 2009 R&D 100 Award  
15 month warranty on any system

[www.americanmagnetics.com](http://www.americanmagnetics.com)

(865)482-1056 • 112 Flint Rd., P.O. Box 2509, Oak Ridge, TN 37831

## COOLING SYSTEMS FOR SUPERCONDUCTIVE DEVICES

System concepts for AC and DC cables, magnets, FCL and rotating machines



## STIRLING CRYOGENICS



- Cooling in 20 to 90K range by GHe flow
- Cooling in 67 to 90K range by sub-cooled LN<sub>2</sub>
- Adjustable cooling power
- Turn-key systems including VJ pipe work and valving
- More than 70 years of experience

**Stirling Cryogenics** (Head Office)

+31 40 26 77 300

[info@stirlingcryogenics.com](mailto:info@stirlingcryogenics.com)

[www.stirlingcryogenics.com](http://www.stirlingcryogenics.com)

Sales Offices in USA, Germany, Sweden and Italy

# Index of Advertisers

Acme Cryogenics .....	19
American Magnetics.....	93
Atlas Technologies. ....	16
Bluefors.....	24
Chart Inc.....	89
CPC-CryoLab.....	87
Cryo Technologies .....	Inside Front Cover
Cryoco LLC .....	7
CryoCoax (Intelliconnect) .....	21
Cryocomp .....	9
Cryofab, Inc. ....	Inside Back Cover
CryoWorks, Inc. ....	9
Gardner Cryogenics.....	17
Lake Shore Cryotronics.....	23
Linde Engineering NA .....	Inside Back Cover
Magnatrol Valve.....	7
OmegaFlex, Inc.....	Back Cover
PHPK Technologies.....	Inside Front Cover
STAR Cryoelectronics .....	7
Stirling Cryogenics.....	93
Sumitomo (SHI) Cryo America.....	3
Technifab.....	87
Tempshield Cryo-Protection .....	87
Vacuum Barrier Corp.....	88
Vacuum Energy .....	93



Join CSA and start receiving **Cold Facts!**

Rates: circle \$ amount

In US: Individual \$85 • Student or retiree: \$40

Outside US: Individual \$130 • Student or retiree \$80

Corporate, in US, number of employees:

1-10, \$495 • 11-25, \$695 • 16-50, \$915 • 51-100, \$1,355  
101-500, \$2,460 • 501-1,000, \$5,515 • 1,000+, \$7,720

Corporate, outside of US, number of employees:

1-10, \$555 • 11-25, \$765 • 16-50, \$990 • 51-100, \$1,400  
101-500, \$2,580 • 501-1,000, \$5,725 • 1,000+, \$8,000

Government/Non-profit: \$475

*Outside the US, please remit in US \$ on US bank. No bank transfers.*

## Charge your membership

Discovery  Visa  MasterCard  AmEx

Account number

Expiration

Security code

Signature

## Please print

Name

Title

Company

Address

City

State/Country

Zip + 4

Email

Website

Phone

Fax

## Send to:

New Memberships • Cryogenic Society of America  
800 Roosevelt Rd. Suite 312-C • Glen Ellyn, IL 60137  
Fax: 630-790-3095

## Join CSA online!

[www.cryogenicsociety.org/membership](http://www.cryogenicsociety.org/membership)

**Cold Facts is the official technical magazine of The Cryogenic Society of America, Inc.** 800 Roosevelt Rd. Suite 312-C • Glen Ellyn, IL 60137

Phone: 630-858-7337 Ext. 8765 • Fax: 630-790-3095

Email: [membership@cryogenicsociety.org](mailto:membership@cryogenicsociety.org) • Web: [cryogenicsociety.org](http://cryogenicsociety.org)

A non-profit technical society serving all those interested in any phase of cryogenics

SSN 1085-5262 • January 2025

Printed in USA



# Connecting Customers With Solutions

Dewars

Containers

Tanks

Cryostats

Transfer Systems

Vacuum  
Components

Vacuum Jacketed  
Valves

VJ Manifolds



**CRYOFAB**

1-800-426-2186 | cryofab.com



## Partner you can count on

For over nine decades, we have been enabling ground-breaking discoveries that challenge the boundaries of physics. As the world's leading cryogenic engineering company, we have the technologies, experience and skills to keep cool – while you unravel the secrets of science.

Linde – your trusted partner.

Linde Engineering Americas  
945 Keystone Avenue, Catoosa, Oklahoma, 74015 USA  
Phone +1 918 266-5700, [linde-engineering.com](http://linde-engineering.com)

Linde Kryotechnik AG  
Daettlikonerstrasse 5, 8422 Pfungen, Switzerland  
Phone +41 52 304-0555, [linde-kryotechnik.ch](http://linde-kryotechnik.ch), [info@linde-kryotechnik.ch](mailto:info@linde-kryotechnik.ch)

**Making our world more productive**





## Cryogenic / Vacuum Jacketed Hose Assemblies

Keep Cryogenic Liquids Cold • Safety Containment



Cryogenic and Vacuum Jacketed Assemblies are oven dried and purged with argon to a moisture content of 2 PPM and verified with a moisture analyzer. Assemblies are helium leak checked to  $1 \times 10^{-9}$  std. cc/sec.; and can be charged with helium to maintain dryness during shipping and storage.

OmegaFlex welders and OmegaFlex welding procedures are qualified to Section IX of the ASME Boiler and Pressure Vessel Code. OmegaFlex hose assemblies are tested in accordance with ISO- 10380:2012.

### Omegaflex Cryogenic / Vacuum Jacketed Hose Assemblies

- Superior insulation properties
- Multi-layer insulation creates a low heat transfer rate
- Minimizes cryogenic liquid boil-off
- Containment of the media in case of inner hose rupture
- Bayonet connections available for quick, leak-resistant installations

### Metal Hose

- Allows for the transfer of liquids or gases, usually at high pressure and high or cryogenic temperature

### Cryogenics Applications

- Nitrogen
- Hydrogen
- Oxygen
- Carbon Dioxide
- Helium
- Argon
- Other Natural Gases

Contact OmegaFlex with your specification and we will engineer a custom jacketed hose assembly for you.

[omegaflex.com](http://omegaflex.com)

© Omega Flex, Inc. 2023



Omega Flex, Inc.  
451 Creamery Way  
Exton, PA 19341  
1-800-671-8622  
ISO 9001 Registered Company  
IND-673 Rev 1223